

Service Hints

E6 (A), E7 (B) Engine and ECT ECU

BATT-Ground : Always approx. 12 volts

IGSW-Ground : Approx. 12 volts with ignition SW at ON or ST position

EOM-Ground : Always continuity

KSW-Ground : Continuity with the key in cylinder

○ : Parts Location

Code		See Page	Code	See Page	Code		See Page
A17		40 (LHD)	I14	41 (LHD)	J5	A	41 (LHD)
		50 (RHD)		51 (RHD)	J7	B	51 (RHD)
E6	A	40 (LHD)	J1	41 (LHD)	U1		41 (LHD)
		50 (RHD)		51 (RHD)			51 (RHD)
E7	B	40 (LHD)	J2	41 (LHD)			
		50 (RHD)		51 (RHD)			

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	25	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
1C		
2G	28	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2M	29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2Q		
2R		
3A	34 (LHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
	35 (RHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace LH)
3B	34 (LHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
	35 (RHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace LH)

□ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF2	60 (LHD)	Engine Room Main Wire and Instrument Panel Wire (Right Side of Steering Column Tube)
	72 (RHD)	Engine Room Main Wire and Instrument Panel Wire (Left Side of Steering Column Tube)
IF4	60 (LHD)	Engine Room Main Wire and Instrument Panel Wire (Right Side of Steering Column Tube)
	72 (RHD)	Engine Room Main Wire and Instrument Panel Wire (Left Side of Steering Column Tube)
II1	62 (LHD)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Reinforcement RH)
	74 (RHD)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)
IK2	62 (LHD)	Engine Wire and Instrument Panel Wire (Behind the Glove Box)
	74 (RHD)	

▽ : Ground Points

Code	See Page	Ground Points Location
ED	56 (LHD 1MZ-FE)	Left Fender
	68 (RHD 1MZ-FE)	
EF	56 (LHD 1MZ-FE)	Rear Side of Surge Tank
	68 (RHD 1MZ-FE)	
II	60 (LHD)	Cowl Side Panel LH
IN	72 (RHD)	Instrument Panel Reinforcement RH