

STEERING SENSOR

REPLACEMENT

1. ☐ PRECAUTION(See page 60-24)
2. ☐ SEPARATE BATTERY NEGATIVE TERMINAL(See page 60-24)
3. ☐ PLACE FRONT WHEELS FACING STRAIGHT AHEAD(See page 60-24)
4. REMOVE STEERING WHEEL COVER LOWER NO.2
(See page 60-24)
5. REMOVE HORN BUTTON ASSY
(See page 60-24)
6. REMOVE STEERING WHEEL ASSY
(See page 60-24)
SST 09950-50013 (09951-05010, 09952-05010, 09953-05020, 09954-05021)
7. REMOVE INSTRUMENT CLUSTER FINISH PANEL
(See page 60-24)
8. REMOVE STEERING COLUMN COVER
(See page 60-24)
9. REMOVE SPIRAL CABLE SUB-ASSY
(See page 60-24)
10. REMOVE STEERING SENSOR
11. INSTALL STEERING SENSOR
12. INSPECT SPIRAL CABLE SUB-ASSY
 - (a) If the following condition is identified, replace the spiral cable sub-assy with new one.
Condition:
Scratches or cracks on the connector
Cracks, dents or chipping of the spiral cable sub-assy
13. ☐ PLACE FRONT WHEELS FACING STRAIGHT AHEAD(See page 60-24)
14. INSTALL SPIRAL CABLE SUB-ASSY
(See page 60-24)
15. ☐ CENTER SPIRAL CABLE(See page 60-24)
16. INSTALL STEERING WHEEL ASSY
(See page 60-24)
17. INSTALL HORN BUTTON ASSY
(See page 60-24)
18. INSPECT HORN BUTTON ASSY
(See page 60-24)
19. ☐ INSPECT SRS WARNING LIGHT(See page 05-511)