


## TC TERMINAL CIRCUIT

### CIRCUIT DESCRIPTION

DTC output mode is set by connecting terminals TC and CG of the DLC3.  
The DTCs are displayed by blinking the SRS warning light.



## WIRING DIAGRAM



## HINT:

When each warning light keeps blinking, a ground short in the wiring of terminal TC of the DLC3 or an internal ground short in each ECU is suspected.

## INSPECTION PROCEDURE


**1 CHECK WIRE HARNESS (DLC3 – AIRBAG SENSOR ASSY CENTER)****DLC3:****Airbag Sensor Assy Center:**H40173  
G27651

H43473

- (a) Turn the ignition switch to the LOCK position.
- (b) Disconnect the airbag sensor assy center connector.
- (c) Measure the resistance according to the value(s) in the table below.

**Standard:**

Tester connection	Condition	Specified condition
D3-13 – A23-15 (TC)	Always	Below 1 $\Omega$

**NG****REPAIR OR REPLACE WIRE HARNESS (TC of DLC3 – TC of AIRBAG SENSOR ASSY CENTER)****OK****2 CHECK WIRE HARNESS (CG of DLC3 – BODY GROUND)****DLC3** **D3**

H40173

- (a) Measure the resistance according to the value(s) in the table below.


**Standard:**

Tester connection	Condition	Specified condition
D3-4 (CG) – Body ground	Always	Below 1 $\Omega$

**NG****REPAIR OR REPLACE WIRE HARNESS (CG of DLC3 – BODY GROUND)****OK**

3

CHECK WIRE HARNESS (TC of AIRBAG SENSOR ASSY CENTER – BODY GROUND)



(a) Measure the resistance according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
A23-15 (TC) – Body ground	Always	1 MΩ or Higher

NG

REPAIR OR REPLACE WIRE HARNESS OR EACH ECU

OK

REPLACE AIR BAG SENSOR ASSY CENTER (SEE PAGE 60-59)