

# I GROUND POINT (RHD)

## : Parts Location

Code	See Page	Code	See Page	Code	See Page
J1	51 (RHD)	J4	51 (RHD)		
J2	51 (RHD)	J11	52 (RHD)		

## : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B (Engine Compartment Left)

## : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1C	25	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
2B	28	
2D		
2L	29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2M		
2R		
3A	35 (RHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace LH)
3B		

## : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	68 (RHD 1MZ-FE)	Engine Room Main Wire and Engine Room No.2 Wire (Radiator Side Support LH)
	70 (*2)	
EA2	68 (RHD 1MZ-FE)	
IB1	72 (RHD)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IE1	72 (RHD)	Instrument Panel Wire and Roof Wire (Inside of Front Right Pillar)
IF4	72 (RHD)	Engine Room Main Wire and Instrument Panel Wire (Left Side of Steering Column Tube)
IF6		
IH1	74 (RHD)	Instrument Panel Wire and Instrument Panel No.3 Wire (Behind the Glove Box)
IK2	74 (RHD)	Engine Wire and Instrument Panel Wire (Behind the Glove Box)
IN1	74 (RHD)	Front Door RH Wire and Floor Wire (Right Kick Panel)
BA1	76 (RHD)	Rear Door LH Wire and Floor No.2 Wire (Left Center Pillar)
BB1	76 (RHD)	Rear Door RH Wire and Floor Wire (Right Center Pillar)
BD1	78 (RHD)	Floor No.2 Wire and Front Seat LH Wire (Under the Front Passenger's Seat)
BE1	78 (RHD)	Floor Wire and Front Seat RH Wire (Under the Driver's Seat)

\* 2 : RHD 2AZ-FE, 1AZ-FE


**: Ground Points**

Code	See Page	Ground Points Location
EA	68 (RHD 1MZ-FE)	Right Fender
	70 (*2)	
EB	68 (RHD 1MZ-FE)	
	70 (*2)	
EC	68 (RHD 1MZ-FE)	Left Fender
	70 (*2)	
ED	68 (RHD 1MZ-FE)	
	70 (*2)	
EE	68 (RHD 1MZ-FE)	Surge Tank RH
EF	68 (RHD 1MZ-FE)	Rear Side of Surge Tank
EG	70 (*2)	Left Side of Cylinder Head
EH	70 (*2)	Intake Side of Cylinder Block
II	72 (RHD)	Instrument Panel Reinforcement LH
IJ		
IK	72 (RHD)	Instrument Panel Brace LH
IL	72 (RHD)	Instrument Panel Brace RH
IM		
IN	72 (RHD)	Instrument Panel Reinforcement RH
BO	76 (RHD)	Under the Front Passenger's Seat
BP	76 (RHD)	Under the Driver's Seat
BQ	76 (RHD)	Front Side of Rear Quarter Wheel House LH
BR	76 (RHD)	Front Side of Rear Quarter Wheel House RH
BS	76 (RHD)	Lower Back Panel Center
BT	76 (RHD)	Rear Quarter Panel LH

\* 2 : RHD 2AZ-FE, 1AZ-FE


**: Splice Points**

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E1	68 (RHD 1MZ-FE)	Engine Room Main Wire	B2	76 (RHD)	Front Door LH Wire
	70 (*2)		B3	76 (RHD)	Front Door RH Wire
E2	68 (RHD 1MZ-FE)		B9	76 (RHD)	Floor Wire
	70 (*2)		B12	76 (RHD)	Rear Door LH Wire
E4	68 (RHD 1MZ-FE)	Engine Wire	B13	76 (RHD)	Rear Door RH Wire
E5	70 (*2)		B14	78 (RHD)	Front Seat LH Wire
I6	74 (RHD)		B15	78 (RHD)	Front Seat RH Wire
I12	74 (RHD)	Instrument Panel Wire	B16	76 (RHD)	Floor Wire
B1	76 (RHD)	Roof Wire			

\* 2 : RHD 2AZ-FE, 1AZ-FE