

## DIAGNOSTIC TROUBLE CODE CHART

DTC No. (See page)	Detection Item	Trouble Area	SRS Warning Light
B0100/13 (05-771)	• SHORT IN D SQUIB CIRCUIT	<ul style="list-style-type: none"> <li>• Horn button assy (squib)</li> <li>• Spiral cable sub-assy</li> <li>• Airbag sensor assy center</li> <li>• Instrument panel wire</li> </ul>	ON
B0101/14 (05-775)	• OPEN IN D SQUIB CIRCUIT	<ul style="list-style-type: none"> <li>• Horn button assy (squib)</li> <li>• Spiral cable sub-assy</li> <li>• Airbag sensor assy center</li> <li>• Instrument panel wire</li> </ul>	ON
B0102/11 (05-779)	• SHORT IN D SQUIB CIRCUIT (TO GROUND)	<ul style="list-style-type: none"> <li>• Horn button assy (squib)</li> <li>• Spiral cable sub-assy</li> <li>• Airbag sensor assy center</li> <li>• Instrument panel wire</li> </ul>	ON
B0103/12 (05-783)	• SHORT IN D SQUIB CIRCUIT (TO B+)	<ul style="list-style-type: none"> <li>• Horn button assy (squib)</li> <li>• Spiral cable sub-assy</li> <li>• Airbag sensor assy center</li> <li>• Instrument panel wire</li> </ul>	ON
B0105/53 (05-787)	• SHORT IN P SQUIB CIRCUIT	<ul style="list-style-type: none"> <li>• Instr pnl pass l/door airbag assy (squib)</li> <li>• Airbag sensor assy center</li> <li>• Instrument panel wire</li> </ul>	ON
B0106/54 (05-790)	• OPEN IN P SQUIB CIRCUIT	<ul style="list-style-type: none"> <li>• Instr pnl pass l/door airbag assy (squib)</li> <li>• Airbag sensor assy center</li> <li>• Instrument panel wire</li> </ul>	ON
B0107/51 (05-793)	• SHORT IN P SQUIB CIRCUIT (TO GROUND)	<ul style="list-style-type: none"> <li>• Instr pnl pass l/door airbag assy (squib)</li> <li>• Airbag sensor assy center</li> <li>• Instrument panel wire</li> </ul>	ON
B0108/52 (05-796)	• SHORT IN P SQUIB CIRCUIT (TO B+)	<ul style="list-style-type: none"> <li>• Instr pnl pass l/door airbag assy (squib)</li> <li>• Airbag sensor assy center</li> <li>• Instrument panel wire</li> </ul>	ON
B0110/43 (05-799)	• SHORT IN SIDE SQUIB (RH) CIR- CUIT	<ul style="list-style-type: none"> <li>• Front seat airbag assy RH (squib)</li> <li>• Airbag sensor assy center</li> <li>• Wire harness</li> </ul>	Blink
B0111/44 (05-802)	• OPEN IN SIDE SQUIB (RH) CIRCUIT	<ul style="list-style-type: none"> <li>• Front seat airbag assy RH (squib)</li> <li>• Airbag sensor assy center</li> <li>• Wire harness</li> </ul>	Blink
B0112/41 (05-805)	• SHORT IN SIDE SQUIB (RH) CIRCUIT (TO GROUND)	<ul style="list-style-type: none"> <li>• Front seat airbag assy RH (squib)</li> <li>• Airbag sensor assy center</li> <li>• Wire harness</li> </ul>	Blink
B0113/42 (05-808)	• SHORT IN SIDE SQUIB (RH) CIRCUIT (TO B+)	<ul style="list-style-type: none"> <li>• Front seat airbag assy RH (squib)</li> <li>• Airbag sensor assy center</li> <li>• Wire harness</li> </ul>	Blink
B0115/47 (05-811)	• SHORT IN SIDE SQUIB (LH) CIRCUIT	<ul style="list-style-type: none"> <li>• Front seat airbag assy LH (squib)</li> <li>• Airbag sensor assy center</li> <li>• Wire harness</li> </ul>	Blink
B0116/48 (05-814)	• OPEN IN SIDE SQUIB (LH) CIRCUIT	<ul style="list-style-type: none"> <li>• Front seat airbag assy LH (squib)</li> <li>• Airbag sensor assy center</li> <li>• Wire harness</li> </ul>	Blink
B0117/45 (05-817)	• SHORT IN SIDE SQUIB (LH) CIRCUIT (TO GROUND)	<ul style="list-style-type: none"> <li>• Front seat airbag assy LH (squib)</li> <li>• Airbag sensor assy center</li> <li>• Wire harness</li> </ul>	Blink
B0118/46 (05-820)	• SHORT IN SIDE SQUIB (LH) CIRCUIT (TO B+)	<ul style="list-style-type: none"> <li>• Front seat airbag assy LH (squib)</li> <li>• Airbag sensor assy center</li> <li>• Wire harness</li> </ul>	Blink
B0121/B0122/ 26*1 (05-823)	• SEAT BELT BUCKLE SWITCH (RH) MALFUNCTION	<ul style="list-style-type: none"> <li>• Front seat inner belt assy (RH)</li> <li>• Airbag sensor assy center</li> <li>• Wire harness</li> </ul>	ON

## DIAGNOSTICS – SUPPLEMENTAL RESTRAINT SYSTEM

B0126/B0127/ 27*2 (05-827)	• SEAT BELT BUCKLE SWITCH (LH) MALFUNCTION	• Front seat inner belt assy (LH) • Airbag sensor assy center • Wire harness	ON
B0130/63 (05-831)	• SHORT IN P/T SQUIB (RH) CIRCUIT	• Seat belt pretensioner RH (squib) • Airbag sensor assy center • Wire harness	Blink
B0131/64 (05-834)	• OPEN IN P/T SQUIB (RH) CIRCUIT	• Seat belt pretensioner RH (squib) • Airbag sensor assy center • Wire harness	Blink
B0132/61 (05-837)	• SHORT IN P/T SQUIB (RH) CIRCUIT (TO GROUND)	• Seat belt pretensioner RH (squib) • Airbag sensor assy center • Wire harness	Blink
B0133/62 (05-840)	• SHORT IN P/T SQUIB (RH) CIRCUIT (TO B+)	• Seat belt pretensioner RH (squib) • Airbag sensor assy center • Wire harness	Blink
B0135/73 (05-843)	• SHORT IN P/T SQUIB (LH) CIRCUIT	• Seat belt pretensioner LH (squib) • Airbag sensor assy center • Wire harness	Blink
B0136/74 (05-846)	• OPEN IN P/T SQUIB (LH) CIRCUIT	• Seat belt pretensioner LH (squib) • Airbag sensor assy center • Wire harness	Blink
B0137/71 (05-849)	• SHORT IN P/T SQUIB (LH) CIRCUIT (TO GROUND)	• Seat belt pretensioner LH (squib) • Airbag sensor assy center • Wire harness	Blink
B0138/72 (05-852)	• SHORT IN P/T SQUIB (LH) CIRCUIT (TO B+)	• Seat belt pretensioner LH (squib) • Airbag sensor assy center • Wire harness	Blink
B1100/31 (05-855)	• AIRBAG SENSOR ASSY CENTER MALFUNCTION	• Airbag sensor assy center	ON
B1135/24 (05-857)	• HALF CONNECTION DETECTION MALFUNCTION	• Airbag sensor assy center	ON
B1140/32 (05-859)	• SIDE AIRBAG SENSOR ASSY (RH) MALFUNCTION	• Side Airbag sensor assy RH • Wire harness	Blink
B1141/33 (05-864)	• SIDE AIRBAG SENSOR ASSY (LH) MALFUNCTION	• Side Airbag sensor assy LH • Wire harness	Blink
B1148/36 (05-869)	• AIRBAG FRONT RH SENSOR MALFUNCTION	• Airbag front RH sensor • Airbag sensor assy center • Engine room main wire harness • Instrument panel wire	ON
B1149/37 (05-876)	• AIRBAG SENSOR FRONT LH MALFUNCTION	• Airbag sensor front LH • Airbag sensor assy center • Engine room main wire harness • Instrument panel wire	ON
B1153/25 (05-883)	• SEAT POSITION AIRBAG SENSOR ASSY MALFUNCTION	• Seat position airbag sensor • Airbag sensor assy center • Wire harness	ON
B1154/38*3 (05-896)	• AIRBAG SENSOR REAR (RH) MALFUNCTION	• Airbag sensor rear (RH) • Airbag sensor assy center • Wire harness	Blink
B1155/39*3 (05-903)	• AIRBAG SENSOR REAR (LH) MALFUNCTION	• Airbag sensor rear (RH) • Airbag sensor assy center • Wire harness	Blink
B1160/83*3 (05-908)	• SHORT IN CURTAIN SHIELD AIRBAG (RH) SQUIB CIRCUIT	• Curtain shield airbag assy RH (squib) • Airbag sensor assy center • Wire harness	Blink
B1161/84*3 (05-911)	• OPEN IN CURTAIN SHIELD AIRBAG (RH) SQUIB CIRCUIT	• Curtain shield airbag assy RH (squib) • Airbag sensor assy center • Wire harness	Blink

B1162/81*3 (05-914)	• SHORT IN CURTAIN SHIELD AIRBAG (RH) CIRCUIT (TO GROUND)	• Curtain shield airbag assy RH (squib) • Airbag sensor assy center • Wire harness	Blink
B1163/82*3 (05-917)	• SHORT IN CURTAIN SHIELD AIRBAG (RH) CIRCUIT (TO B+)	• Curtain shield airbag assy RH (squib) • Airbag sensor assy center • Wire harness	Blink
B1165/87*3 (05-920)	• SHORT IN CURTAIN SHIELD AIRBAG (LH) SQUIB CIRCUIT	• Curtain shield airbag assy LH (squib) • Airbag sensor assy center • Wire harness	Blink
B1166/88*3 (05-923)	• OPEN IN CURTAIN SHIELD AIRBAG (LH) SQUIB CIRCUIT	• Curtain shield airbag assy LH (squib) • Airbag sensor assy center • Wire harness	Blink
B1167/85*3 (05-926)	• SHORT IN CURTAIN SHIELD AIRBAG (LH) CIRCUIT (TO GROUND)	• Curtain shield airbag assy LH (squib) • Airbag sensor assy center • Wire harness	Blink
B1168/86*3 (05-929)	• SHORT IN CURTAIN SHIELD AIRBAG (LH) CIRCUIT (TO B+)	• Curtain shield airbag assy LH (squib) • Airbag sensor assy center • Wire harness	Blink
B1180/17 (05-932)	• SHORT IN D SQUIB (2ND STEP) CIRCUIT	• Horn button assy (D squib (2nd step)) • Spiral cable sub-assy • Airbag sensor assy center • Wire harness	ON
B1181/18 (05-936)	• OPEN IN D SQUIB (2ND STEP) CIRCUIT	• Horn button assy (D squib (2nd step)) • Spiral cable sub-assy • Airbag sensor assy center • Wire harness	ON
B1182/19 (05-940)	• SHORT IN D SQUIB (2ND STEP) CIRCUIT (TO GROUND)	• Horn button assy (D squib (2nd step)) • Spiral cable sub-assy • Airbag sensor assy center • Wire harness	ON
B1183/22 (05-944)	• SHORT IN D SQUIB (2ND STEP) CIRCUIT (TO B+)	• Horn button assy (D squib (2nd step)) • Spiral cable sub-assy • Airbag sensor assy center • Wire harness	ON
B1185/57 (05-948)	• SHORT IN P SQUIB (2ND STEP) CIRCUIT	• Instr pnl pass l/door airbag assy (P squib (2nd step)) • Airbag sensor assy center • Instrument panel wire	ON
B1186/58 (05-951)	• OPEN IN P SQUIB (2ND STEP) CIRCUIT	• Instr pnl pass l/door airbag assy (P squib (2nd step)) • Airbag sensor assy center • Instrument panel wire	ON
B1187/55 (05-954)	• SHORT IN P SQUIB (2ND STEP) CIRCUIT (TO GROUND)	• Instr pnl pass l/door airbag assy (P squib (2nd step)) • Airbag sensor assy center • Instrument panel wire	ON
B1188/56 (05-957)	• SHORT IN P SQUIB (2ND STEP) CIRCUIT (TO B+)	• Instr pnl pass l/door airbag assy (P squib (2nd step)) • Airbag sensor assy center • Instrument panel wire	ON
Normal (05-960)	• SYSTEM NORMAL	–	OFF
	• VOLTAGE SOURCE DROP	• Battery • Airbag sensor assy center	ON

\*1: RHD, \*2: LHD, \*3: w/ Curtain Shield Airbag

#### HINT:

- When the SRS warning light remains lit up and the DTC is the normal code, this means a voltage source drops.  
This malfunction is not stored in memory by the Airbag sensor assy center and if the power source voltage returns to normal, the SRS warning light will automatically go out.
- When 2 or more codes are indicated, the codes will be displayed in numeral order starting from the lowest numbered code.
- If a code not listed on the chart is displayed, the Airbag sensor assy center is faulty.