

LIGHT AUTO TURN OFF SYSTEM LIGHT DOES NOT OPERATE**INSPECTION PROCEDURE****1 INSPECT FRONT DOOR COURTESY LAMP SWITCH ASSY**

(a) Inspect front door courtesy lamp switch continuity.

(1) Check that there is continuity between terminal 1 and body ground when switch is operated.

Standard:

ON (When shaft is pressed): No continuity

OFF (When shaft is not pressed): Continuity

NG

REPLACE FRONT DOOR COURTESY LAMP SWITCH ASSY (DRIVER SIDE DOOR)

OK

2 INSPECT INSTRUMENT PANEL JUNCTION BLOCK ASSY(ACC)

(a) Measure voltage between terminal 2A-7 (ACC) of instrument panel J/B assy and body ground.

Standard:

IG switch	Tester connection	Specified condition
ACC	2A-7 (ACC) – Body ground	10 – 14 V
OFF	2A-7 (ACC) – Body ground	Below 1 V

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR (POWER SOURCE)

OK

CHECK AND REPLACE INSTRUMENT PANEL JUNCTION BLOCK ASSY