


OVERHAUL

HINT:

- COMPONENT: SEE PAGE 72-30.
- Installation is in the reverse order of removal.
- Only installation procedures requiring additional information are included.
- A bolt without a torque specification is shown in the standard bolt chart (see page 03-2).

1. **REMOVE REAR DOOR SCUFF PLATE LH (SEE PAGE 76-22)**
2. **REMOVE REAR DOOR SCUFF PLATE RH (SEE PAGE 76-22)**




3. REMOVE REAR SEAT CUSHION ASSY

- (a) Pull up the 2 portions of the rear seat cushion assy as shown in the illustration and remove it.

A: 100 mm (3.94 in.) or less


NOTICE:

In this case, hold the base of the clip up to prevent the cushion frame from being distorted.



4. REMOVE REAR SEAT BACK ASSY LH

- (a) Remove the rear seat belt from the rear seat shoulder belt guide center.




- (b) Fold the rear seat assy LH forward and open the separate type rear seat back cover.
- (c) Remove the 2 bolts and the rear seat back assy LH.

5. REMOVE REAR SEAT BACK ASSY RH

HINT:

Use the same procedures for the RH side and LH side.




6. REMOVE REAR SIDE SEAT BACK ASSY LH

- (a) Remove the bolt and the rear side seat back assy LH as shown in the illustration.

7. REMOVE REAR SIDE SEAT BACK ASSY RH

HINT:

Use the same procedures for the RH side and LH side.




8. REMOVE REAR SEAT BACK HINGE SUB-ASSY LH

- (a) Remove the bolt and the rear seat back hinge sub-assy LH.

9. REMOVE REAR SEAT BACK HINGE SUB-ASSY RH

HINT:

Use the same procedures for the RH side and LH side.






10. REMOVE REAR SEAT BACK HINGE SUB-ASSY CENTER

- (a) Remove the 2 bolts and the rear seat back hinge sub-assy center.

11. REMOVE BENCH TYPE REAR SEAT CUSHION COVER


- (a) Remove the 56 hog rings and the bench type rear seat cushion cover.

**12. REMOVE REAR SEAT HEADREST ASSY****13. REMOVE REAR SEAT HEADREST ASSY CENTER****14. REMOVE REAR SEAT BACK LOCK RELEASE BUTTON**

- (a) Remove the rear seat back lock release button as shown in the illustration.

HINT:

Use the same procedures for the RH side and LH side.




15. REMOVE REAR SEAT SHOULDER BELT GUIDE CENTER

- (a) Remove the 2 screws and the rear seat shoulder belt guide center.

HINT:

Use the same procedures for the RH side and LH side.




16. REMOVE REAR SEAT BACK LOCK CONTROL BEZEL

- (a) Remove the screw and the rear seat back lock control bezel.


HINT:

Use the same procedures for the RH side and LH side.




17. REMOVE REAR SEAT BACK HINGE COVER

- (a) Remove the rear seat back hinge cover.




18. REMOVE REAR SEAT ARMREST ASSY CENTER

- (a) Remove the bolt and the rear seat armrest assy center.




19. REMOVE REAR SEAT BACK STOP BUTTON GROMMET

- (a) Remove the rear seat back stop button grommet.




20. REMOVE REAR SEAT HEADREST SUPPORT

- (a) Disengage the separate type rear seat back cover and turn back the sides of the cover.
- (b) Turn back the separate type rear seat back cover and remove the 13 hog rings.




- (c) Disengage the 6 claws and remove the 3 rear seat headrest supports.



21. REMOVE REAR SEAT HEADREST SUPPORT


HINT:

Use the same procedures for the RH side and LH side.





22. REMOVE SEPARATE TYPE REAR SEAT BACK COVER

- (a) Remove the 5 hog rings and the separate type rear seat back cover.



23. REMOVE SEPARATE TYPE REAR SEAT BACK COVER

- (a) Remove the 12 hog rings and the separate type rear seat back cover.




24. REMOVE REAR SEAT BACK LOCK ASSY LH

- (a) Remove the 3 bolts and the rear seat back lock assy LH.

25. REMOVE REAR SEAT BACK LOCK ASSY RH

HINT:

Use the same procedures for the RH side and LH side.



26. INSTALL REAR SEAT BACK LOCK ASSY LH


- (a) Install the rear seat back lock assy LH with the 3 bolts.
Torque: 20 N·m (204 kgf·cm, 15 ft·lbf)

27. INSTALL REAR SEAT BACK LOCK ASSY RH

Torque: 20 N·m (204 kgf·cm, 15 ft·lbf)

HINT:

Use the same procedures for the RH side and LH side.






28. INSTALL SEPARATE TYPE REAR SEAT BACK COVER

- (a) Using hog ring pliers, install the separate type rear seat back cover with 12 new hog rings.

NOTICE:

- **Be careful not to damage the cover.**
- **When installing the hog rings, take care to minimize wrinkles as much as possible.**







29. INSTALL SEPARATE TYPE REAR SEAT BACK COVER

- (a) Using hog ring pliers, install the separate type rear seat back cover with 5 new hog rings.

NOTICE:

- Be careful not to damage the cover.
- When installing the hog rings, take care to minimize wrinkles as much as possible.








30. INSTALL BENCH TYPE REAR SEAT CUSHION COVER

- (a) Using hog ring pliers, install the bench type rear seat cushion cover with 56 new hog rings.

NOTICE:

- Be careful not to damage the cover.
- When installing the hog rings, take care to minimize wrinkles as much as possible.






31. INSTALL REAR SEAT BACK HINGE SUB-ASSY CENTER

- (a) Install the rear seat back hinge sub-assy center with the 2 bolts.

Torque: 18 N·m (184 kgf·cm, 13 ft·lbf)



32. INSTALL REAR SEAT BACK HINGE SUB-ASSY LH

- (a) Install the rear seat back hinge sub-assy LH with the bolt.


Torque: 18 N·m (184 kgf·cm, 13 ft·lbf)

33. INSTALL REAR SEAT BACK HINGE SUB-ASSY RH

Torque: 18 N·m (184 kgf·cm, 13 ft·lbf)

HINT:

Use the same procedures for the RH side and LH side.



34. INSTALL REAR SIDE SEAT BACK ASSY LH

- (a) Install the rear side seat back assy LH with the bolt.


Torque: 18 N·m (184 kgf·cm, 13 ft·lbf)

35. INSTALL REAR SIDE SEAT BACK ASSY RH

Torque: 18 N·m (184 kgf·cm, 13 ft·lbf)

HINT:

Use the same procedures for the RH side and LH side.




36. INSTALL REAR SEAT BACK ASSY LH

- (a) Install the rear seat back assy LH with the 2 bolts.

Torque: 18 N·m (184 kgf·cm, 13 ft·lbf)

- (b) Close the separate type rear seat back cover and put back the rear seat back assy LH.



- (c) Install the rear seat belt to the rear seat shoulder belt guide center.

37. INSTALL REAR SEAT BACK ASSY RH

Torque: 18 N·m (184 kgf·cm, 13 ft·lbf)

HINT:

Use the same procedures for the RH side and LH side.