



F RELAY LOCATIONS


[Engine Compartment]




[Body]



[Instrument Panel]




[Seat]



F RELAY LOCATIONS


① : Engine Room R/B

Engine Compartment Left (See Page 20)



② : ABS R/B


Radiator Side Support LH (See Page 20)




F RELAY LOCATIONS

 : Engine Room J/B


Engine Compartment Left (See Page 20)





F RELAY LOCATIONS


[Engine Room J/B Inner Circuit]




F RELAY LOCATIONS

 : Driver Side J/B


Lower Finish Panel (See Page 21)






F RELAY LOCATIONS

[Driver Side J/B Inner Circuit]



(Cont. next page)


(Cont'd)




(Cont. next page)

F RELAY LOCATIONS

[Driver Side J/B Inner Circuit]




When conducting continuity test inside the plate, see the plate and terminal ID number (View 1) shown below as well as the inside-the-plate wiring connection diagram




F RELAY LOCATIONS

 : Passenger Side J/B

Instrument Panel Brace RH (See Page 21)




Short Terminal Grouping



F RELAY LOCATIONS

Junction Connector	Instrument Panel Center (See Page 21)
--------------------	---------------------------------------



[Junction Connector Inner Circuit]

J13(A), J14(B), J15(C), J16(D), J17(E)
Junction Connector

