


POWER SOURCE CIRCUIT (STEREO COMPONENT AMPLIFIER ASSY)

CIRCUIT DESCRIPTION


This circuit provides power to the stereo component amplifier assy.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 INSPECT STEREO COMPONENT AMPLIFIER ASSY(+B, ACC, GND)



- (a) Disconnect the stereo component amplifier assy connector S12, S13.
- (b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
GND – Body ground	Always	Below 1 Ω

- (c) Measure the voltage according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
+B – GND	Always	10 to 14 V
ACC – GND	Ignition SW ACC	10 to 14 V

NG

REPAIR OR
CONNECTOR

REPLACE HARNESS OR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE OR DIAGNOSTIC TROUBLE CODE CHART (SEE PAGE 05-1914 OR 05-1910)