


REPLACEMENT


HINT:

- Installation is in the reverse order of removal.
- COMPONENTS: [SEE PAGE 76-1](#).



1. REMOVE FRONT BUMPER ASSY


- (a) Remove the clip and the 2 bolts.




- (b) Turn the pin hold clip 90° as shown in the illustration and remove it. (LH side)

HINT:

Remove the RH side by following the same procedure as for the LH side.



- (c) Remove the 9 screws.




- (d) Disengage the 3 claws by pulling the left side of the front bumper cover in the direction shown by the arrow. (LH side)

HINT:


Disengage the RH side by following the same procedure as for the LH side.

- (e) Disconnect the fog lamp connector (w/ fog lamp) and remove the front bumper Assy.




2. REMOVE FRONT BUMPER COVER LOWER

- (a) Disengage the 2 claws and remove the front bumper cover lower.



3. REMOVE FRONT BUMPER EXTENSION MOUNTING BRACKET

- (a) Remove the 2 screws and the bumper extension mounting bracket.




4. REMOVE FRONT BUMPER HOLE COVER LH (W/O FOG LAMP)

- (a) Remove the 2 screws and the front bumper hole cover LH.

5. REMOVE FRONT BUMPER HOLE COVER RH (W/O FOG LAMP)


6. REMOVE FOG LAMP ASSY LH (W/ FOG LAMP) (SEE PAGE 65-11)

7. REMOVE FOG LAMP ASSY RH (W/ FOG LAMP) (SEE PAGE 65-11)




8. REMOVE FRONT BUMPER ENERGY ABSORBER

- (a) Remove the front bumper energy absorber.




9. REMOVE FRONT BUMPER REINFORCEMENT SUB-ASSY

- (a) Disengage the 5 clamps.




- (b) Remove the 6 bolts and the front bumper reinforcement sub-assy.



10. REMOVE FRONT BUMPER REINFORCEMENT SUB-ASSY UPPER


- (a) Remove the 2 bolts and the 2 nuts.
(b) Remove the front bumper reinforcement sub-assy upper.



11. REMOVE FRONT BUMPER REINFORCEMENT EXTENSION LH

- (a) Remove the 2 bolts and the nut.
- (b) Remove the front bumper reinforcement extension LH.

12. REMOVE FRONT BUMPER REINFORCEMENT EXTENSION RH



13. INSTALL FRONT BUMPER REINFORCEMENT EXTENSION LH


- (a) Install the front bumper reinforcement extension LH with the 2 bolts and nut.

Torque: 8.5 N·m (87 kgf·cm, 75 in·lbf)

14. INSTALL FRONT BUMPER REINFORCEMENT EXTENSION RH

- (a) Install the front bumper reinforcement extension RH with the 2 bolts and nut.


Torque: 8.5 N·m (87 kgf·cm, 75 in·lbf)



15. INSTALL FRONT BUMPER REINFORCEMENT SUB-ASSY UPPER

- (a) Install the front bumper reinforcement sub-assy upper with the 2 bolts and 2 nuts.

Torque: 8.5 N·m (87 kgf·cm, 75 in·lbf)



16. INSTALL FRONT BUMPER REINFORCEMENT SUB-ASSY

- (a) Install the front bumper reinforcement sub-assy with the 6 bolts.

Torque: 34 N·m (347 kgf·cm, 25 ft·lbf)

17. FOG LAMP AIMING ADJUSTMENT (W/ FOG LAMP) (SEE PAGE 65-12)