



### 3 RECONFIRM DTC (See page 05-511)

A	Normal Code
B	Malfunction Code

B

REPAIR CIRCUIT INDICATED BY OUTPUT CODE

A

### 4 INSPECT COMBINATION METER ASSY (BRAKE WARNING LIGHT CIRCUIT)

NG

REPAIR OR REPLACE COMBINATION METER ASSY

OK

### 5 CHECK HARNESS AND CONNECTOR (COMBINATION METER - SKID CONTROL ECU ASSY) (See page 01-31)

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

CHECK AND REPLACE SKID CONTROL ECU ASSY