

SRS WARNING LIGHT CIRCUIT MALFUNCTION (DOES NOT LIGHT UP, WHEN IGNITION SWITCH IS TURNED TO ON)

CIRCUIT DESCRIPTION

The SRS warning light is located on the combination meter assy.

When the SRS is normal, the SRS warning light comes on for approximately 6 seconds after the ignition switch is turned from the LOCK to ON position, and then goes off automatically.

If there is a malfunction in the SRS, the SRS warning light comes on to inform the driver of a problem.

When terminals TC and CG of the DLC3 are connected, the DTC is displayed by blinking the SRS warning light.

WIRING DIAGRAM

See page [05-1777](#).

INSPECTION PROCEDURE

CAUTION:

Be sure to perform the following procedures before troubleshooting to avoid unexpected airbag deployment.

- (a) Turn the ignition switch to the LOCK position.
- (b) Disconnect the negative (–) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Disconnect the connectors from the airbag sensor assy center.
- (d) Disconnect the connectors from the horn button assy.
- (e) Disconnect the connectors from the front passenger airbag assy.
- (f) w/ Side airbag:
Disconnect the connector from the front seat airbag assy LH.
- (g) w/ Side airbag:
Disconnect the connector from the front seat airbag assy RH.
- (h) w/ Curtain shield airbag:
Disconnect the connector from the curtain shield airbag assy LH.
- (i) w/ Curtain shield airbag:
Disconnect the connector from the curtain shield airbag assy RH.
- (j) Disconnect the connector from the front seat outer belt assy LH.
- (k) Disconnect the connector from the front seat outer belt assy RH.

1 CHECK BATTERY

- (a) Measure the voltage of the battery.

Standard: 11 to 14 V


NG

REPLACE BATTERY

OK

2 CHECK COMBINATION METER ASSY

- Disconnect the negative (–) terminal cable from the battery, and wait for at least 90 seconds.
- Disconnect the connectors from the airbag sensor assy center.
- Connect the negative (–) terminal cable to the battery, and wait for at least 2 seconds.
- Turn the ignition switch to the ON position.
- Check the SRS warning light operation.

OK:**The SRS warning light does not come on.****NG****REPLACE AIR BAG SENSOR ASSY CENTER
(SEE PAGE 60-59)****OK****3 CHECK WIRE HARNESS (COMBINATION METER ASSY – AIRBAG SENSOR ASSY CENTER)**

- Turn the ignition switch to the LOCK position.
- Disconnect the negative (–) terminal cable from the battery, and wait for at least 90 seconds.
- Disconnect the connector from the combination meter assy.
- Connect the negative (–) terminal cable to the battery, and wait for at least 2 seconds.
- Measure the voltage according to the value(s) in the table below.

Standard:

| Tester connection | Condition | Specified condition |
|------------------------------|--------------------|---------------------|
| A23-14 (LA) – Body ground | Ignition switch ON | Below 1 V |

NG**REPAIR OR REPLACE WIRE HARNESS****OK****REPLACE COMBINATION METER ASSY (SEE PAGE 71-16)**