





Clock

: Parts Location

Code		See Page	Code		See Page	Code		See Page
A1		38 (*1)	C10		42	J7	A	43
		40 (*2)	F8		44	J8	B	43
A13	A	42	I7	A	39 (*1)	R13		43
A23	B	42			41 (*2)	S1	A	39 (*1)
A40	B	42		39 (*1)	B			41 (*2)
C5	A	42		41 (*2)			C	39 (*1)
	B	42	J2	43	41 (*2)			
C7	A	42	J5	A	43		39 (*1)	
C8	B	42	J6	B	43		41 (*2)	

: Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B (Engine Compartment Left)

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1L	25	Engine Wire and Engine Room J/B (Engine Compartment Left)
2E	28	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2K	28	Floor Wire and Driver Side J/B (Lower Finish Panel)
2L	29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2M		
2O		
2R		
3A	34	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
3B		

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	50	Instrument Panel Wire and Floor Wire (Left Kick Panel)
IF3	50	Engine Room Main Wire and Instrument Panel Wire (Right Side of Steering Column Tube)
IF4		
IJ1	51	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Reinforcement RH)
IL1	51	Engine Wire and Instrument Panel Wire (Behind the Glove Box)

: Ground Points

Code	See Page	Ground Points Location
II	50	Cowl Side Panel LH

* 1 : 1MZ-FE, 3MZ-FE * 2 : 2AZ-FE * 3 : w/ Power Seat * 4 : w/o Power Seat

