


INSPECTION



1. INSPECT FRONT DOOR W/MOTOR LOCK ASSY RH

(a) Inspect operation of the door lock motor.

Standard:

Measurement condition	Operation
Battery positive - Terminal 4 Battery negative - Terminal 1	Lock
Battery positive - Terminal 1 Battery negative - Terminal 4	Unlock


If operation is not as specified, replace the door lock assembly.

(b) Inspect the position switch continuity.

Standard:

Terminals No.	Door lock position	Specification
7 ↔ 8	Lock	No continuity
	Unlock	Continuity

If the continuity is not as specified, replace the door lock assembly.




2. INSPECT FRONT DOOR W/MOTOR LOCK ASSY LH

(a) Inspect the door lock assembly continuity.

Standard:

Terminals No.	Switch position	Specified condition
9 - 7	Lock	Continuity
-	OFF	No continuity
10 - 7	Unlock	Continuity

If the continuity is not as specified, replace the door lock assembly.



(b) Inspect operation of the door lock motor.

Standard:

Measurement condition	Operation
Battery positive – Terminal 4 Battery negative – Terminal 1	Lock
Battery positive – Terminal 1 Battery negative – Terminal 4	Unlock


If operation is not as specified, replace the door lock assembly.

(c) Inspect the position switch continuity.

Standard:

Terminals No.	Door lock position	Specification
7 ↔ 8	Lock	No continuity
	Unlock	Continuity

If the continuity is not as specified, replace the door lock assembly.



3. INSPECT REAR DOOR W/MOTOR LOCK ASSY RH

(a) Inspect operation of the door lock motor.

Standard:

Measurement condition	Operation
Battery positive – Terminal 4 Battery negative – Terminal 1	Lock
Battery positive – Terminal 1 Battery negative – Terminal 4	Unlock


If operation is not as specified, replace the door lock assembly.

(b) Inspect the position switch continuity.

Standard:

Terminals No.	Door lock position	Specification
6 ↔ 9	Lock	No continuity
	Unlock	Continuity

If the continuity is not as specified, replace the door lock assembly.



4. INSPECT REAR DOOR W/MOTOR LOCK ASSY LH

- (a) Inspect operation of the door lock motor.

Standard:

Measurement condition	Operation
Battery positive – Terminal 4 Battery negative – Terminal 1	Lock
Battery positive – Terminal 1 Battery negative – Terminal 4	Unlock


If operation is not as specified, replace the door lock assembly.

- (b) Inspect the position switch continuity.

Standard:

Terminals No.	Door lock position	Specification
6 ↔ 9	Lock	No continuity
	Unlock	Continuity

If the continuity is not as specified, replace the door lock assembly.



5. INSPECT LUGGAGE COMPARTMENT DOOR LOCK ASSY

- (a) Inspect operation of the door lock motor.

Standard:

Measurement condition	Operation
Battery positive – Terminal 1 Battery negative – Lock body	Open

If operation is not as specified, replace the door lock assembly.