

Service Hints

M3 Moon Roof Control ECU and Motor

8—Ground : Approx. 12 volts with ignition SW at ON or ST position

5—Ground : Always approx. 12 volts

7—Ground : Always continuity

○ : Parts Location

Code		See Page	Code		See Page	Code	See Page
B7	C	40 (LHD)	J7	A	41 (LHD)	M4	43 (LHD)
		50 (RHD)	J13	B	51 (RHD)		53 (RHD)
D6		42 (LHD)	M3		43 (LHD)		
D7		52 (RHD)			53 (RHD)		

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2B	28	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2R	29	

□ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC2	60 (LHD)	Instrument Panel Wire and Floor Wire (Left Kick Panel)
	72 (RHD)	Instrument Panel Wire and Floor Wire (Right Kick Panel)
IE1	60 (LHD)	Instrument Panel Wire and Roof Wire (Inside of Front Left Pillar)
	72 (RHD)	Instrument Panel Wire and Roof Wire (Inside of Front Right Pillar)

▽ : Ground Points

Code	See Page	Ground Points Location
II	60 (LHD)	Cowl Side Panel LH
IJ	72 (RHD)	Instrument Panel Reinforcement LH
IM	60 (LHD)	Instrument Panel Reinforcement RH
IN	72 (RHD)	