

Service Hints

FOG Relay

5-3 : Closed with the light control SW at TAIL or HEAD position and front fog light SW on

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
B7	40 (LHD)	F3	36 (LHD 1MZ-FE)	F4	38 (*1)
C7	40 (LHD)		38 (*1)		46 (RHD 1MZ-FE)
	50 (RHD)		46 (RHD 1MZ-FE)		48 (*2)
C11	40 (LHD)		48 (*2)	J12	41 (LHD)
	50 (RHD)	F4	36 (LHD 1MZ-FE)		

* 1 : LHD 2AZ-FE, 1AZ-FE * 2 : RHD 2AZ-FE, 1AZ-FE

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2C	28	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2G	28	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2M	29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2O		
2P		
2Q		
2R		
3A	34 (LHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
	35 (RHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace LH)
3B	34 (LHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
	35 (RHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace LH)

▽ : Ground Points

Code	See Page	Ground Points Location
EB	56 (LHD 1MZ-FE)	Right Fender
	58 (*1)	
	68 (RHD 1MZ-FE)	
	70 (*2)	
EC	56 (LHD 1MZ-FE)	Left Fender
	58 (*1)	
	68 (RHD 1MZ-FE)	
	70 (*2)	
II	60 (LHD)	Cowl Side Panel LH
IN	72 (RHD)	Instrument Panel Reinforcement RH

* 1 : LHD 2AZ-FE, 1AZ-FE * 2 : RHD 2AZ-FE, 1AZ-FE

⬡ : Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I3	62 (LHD)	Engine Room Main Wire	I3	74 (RHD)	Engine Room Main Wire