

Service Hints

B8 Buckle SW LH

4-1 : Closed with seat belt in use

B9 Buckle SW RH

4 (LHD), 2 (RHD)-1 : Closed with seat belt in use

○ : Parts Location

Code		See Page	Code		See Page	Code	See Page
A26	A	40 (LHD)	A28	C	50 (RHD)	C5	40 (LHD)
		50 (RHD)			44 (LHD)		50 (RHD)
A27	B	40 (LHD)	B8	B	54 (RHD)	C7	40 (LHD)
		50 (RHD)			44 (LHD)		50 (RHD)
A28	C	40 (LHD)	B9	B	54 (RHD)		

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2K	28	Floor Wire and Driver Side J/B (Lower Finish Panel)
2M	29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2N		
2R		
3A	34 (LHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
	35 (RHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace LH)
3B	34 (LHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
	35 (RHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace LH)

□ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	60 (LHD)	Instrument Panel Wire and Floor Wire (Left Kick Panel)
	72 (RHD)	Instrument Panel Wire and Floor Wire (Right Kick Panel)
IM3	62 (LHD)	Instrument Panel Wire and Floor No.2 Wire (Right Kick Panel)
	74 (RHD)	Instrument Panel Wire and Floor No.2 Wire (Left Kick Panel)
BD1	66 (LHD)	Floor Wire and Front Seat LH Wire (Under the Driver's Seat)
	78 (RHD)	Floor No.2 Wire and Front Seat LH Wire (Under the Front Passenger's Seat)
BE1	66 (LHD)	Floor No.2 Wire and Front Seat RH Wire (Under the Front Passenger's Seat)
	78 (RHD)	Floor Wire and Front Seat RH Wire (Under the Driver's Seat)

▽ : Ground Points

Code	See Page	Ground Points Location
II	60 (LHD)	Cowl Side Panel LH
IN	72 (RHD)	Instrument Panel Reinforcement RH
BO	64 (LHD)	Under the Driver's Seat
	76 (RHD)	Under the Front Passenger's Seat
BP	64 (LHD)	Under the Front Passenger's Seat
	76 (RHD)	Under the Driver's Seat