

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See page
Driver's seat belt warning lamp does not light up	1. GAUGE Fuse	-
	2. Combination meter	71-6
	3. Air bag sensor assembly center	05-755
	4. Front seat inner belt assy LH	61-3
	5. Wire harness	-
Passenger's seat belt warning lamp does not light up	1. GAUGE Fuse	-
	2. Clock assembly	71-6
	3. Front seat inner belt assy RH	61-3
	4. Wire harness	-