


# INSPECTION



## 1. INSPECT FRONT POWER SEAT SWITCH LH

(a) Inspect the front power seat switch continuity.

### Standard (Slide switch):

Terminal No.	Switch position	Specified condition
1 ⇔ 9 4 ⇔ 6	FRONT	Continuity
6 ⇔ 4 ⇔ 9	OFF	Continuity
4 ⇔ 9 1 ⇔ 6	REAR	Continuity

### Standard (Front vertical switch):

Terminal No.	Switch position	Specified condition
1 ⇔ 10 4 ⇔ 5	UP	Continuity
5 ⇔ 4 ⇔ 10	OFF	Continuity
1 ⇔ 5 4 ⇔ 10	DOWN	Continuity


### Standard (Rear vertical switch):

Terminal No.	Switch position	Specified condition
1 ⇔ 7 4 ⇔ 8	UP	Continuity
7 ⇔ 4 ⇔ 8	OFF	Continuity
1 ⇔ 8 4 ⇔ 7	DOWN	Continuity

### Standard (Reclining switch):

Terminal No.	Switch position	Specified condition
1 ⇔ 3 2 ⇔ 4	FRONT	Continuity
2 ⇔ 4 ⇔ 3	OFF	Continuity
1 ⇔ 2 3 ⇔ 4	REAR	Continuity

If the result is not as specified, replace the front power switch.



## 2. INSPECT FRONT POWER SEAT SWITCH RH

- (a) Inspect the front power seat switch continuity.

### Standard (Slide switch):

Terminal No.	Switch position	Specified condition
1 ⇔ 9 4 ⇔ 6	FRONT	Continuity
6 ⇔ 4 ⇔ 9	OFF	Continuity
4 ⇔ 9 1 ⇔ 6	REAR	Continuity

### Standard (Front vertical switch):

Terminal No.	Switch position	Specified condition
1 ⇔ 5 4 ⇔ 10	UP	Continuity
5 ⇔ 4 ⇔ 10	OFF	Continuity
1 ⇔ 10 4 ⇔ 5	DOWN	Continuity


### Standard (Rear vertical switch):

Terminal No.	Switch position	Specified condition
1 ⇔ 8 4 ⇔ 7	FRONT	Continuity
7 ⇔ 4 ⇔ 8	OFF	Continuity
1 ⇔ 7 4 ⇔ 8	REAR	Continuity

### Standard (Reclining switch):

Terminal No.	Switch position	Specified condition
1 ⇔ 3 2 ⇔ 4	FRONT	Continuity
2 ⇔ 4 ⇔ 3	OFF	Continuity
1 ⇔ 2 3 ⇔ 4	REAR	Continuity

If the result is not as specified, replace the front power switch.




## 3. INSPECT FRONT UP, DOWN POWER SEAT MOTOR ASSY

- (a) Inspect the front up, down power seat motor operation.
- (1) Check that the motor rotates smoothly when the battery is connected to the connector terminal.

### Standard:

Tester Condition	Specified Condition
Battery positive voltage ⇔ 1 Battery negative voltage ⇔ 2	Counterclockwise
Battery positive voltage ⇔ 2 Battery negative voltage ⇔ 1	Clockwise

If the result is not as specified, replace the front power seat motor.



4. INSPECT POWER SEAT MOTOR ASSY

- (a) Inspect the power seat motor operation.
- (1) Check that the motor rotates smoothly when the battery is connected to the connector terminal.

**Standard:**

Tester Condition	Specified Condition
Battery positive voltage ⇔ 1 Battery negative voltage ⇔ 2	Counterclockwise
Battery positive voltage ⇔ 2 Battery negative voltage ⇔ 1	Clockwise

If the result is not as specified, replace the front power seat motor.