


CHECKING MONITOR STATUS

HINT:

"MONITOR RESULT" indicates normal or malfunction of each component and system when a judgment was made.




1. HOW TO READ DATA

- Connect the hand-held tester to the DLC3.
- Enter the following menus: DIAGNOSIS / ENHANCED OBD II / MONITOR INFO / MONITOR RESULT.


The Test ID will appear at the beginning of each line, followed by INCMP, PASS, or FAIL.

HINT:

- INCMP: Stands for "incomplete". The judgement has not been done yet.
 - PASS: Normal is detected.
 - FAIL: A malfunction has been detected.
- Select a Test ID from the list and press "ENTER" The following screen will appear:



- | | | |
|-----|------------------|---------------------|
| (1) | VAL (TEST VALUE) | [Test Data] [Unit] |
| (2) | LMT (TEST LIMIT) | [Test Limit] [Unit] |
| (3) | TLT | [Test Limit Type] |



- By pressing the "HELP" button, you can see more information.

HINT:

- Monitor test results can be viewed in the MONITOR RESULT screen.
- Monitor test results indicate the latest malfunction judgement result of this diagnostic.
- TEST VALUE indicates the detection parameter value (Example: P0128 Thermostat Malfunction = Engine coolant temperature) at the time of malfunction (or normal) judgement is done.
- TEST LIMIT indicates a threshold of malfunction judgement (Example: P0128 Thermostat Malfunction = 75°C).
- When the monitor runs, the monitored Parameter's VALUE is recorded. The value is then compared to the TEST LIMIT to determine if the result is PASS or FAIL.
- By comparing the Parameter VALUE to the TEST LIMIT, it is possible to determine the degree of failure.

- In rare cases, the monitor may have passed even with a DTC set and MIL illuminated. The monitor possibly detect malfunction on a previous trip, and then passed on the most recent trip. This would indicated an intermittent problem may be the cause of the DTC.