

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See page
Seat heaters do not operate	1. SEAT HTR fuse	–
	2. Front seat cushion heater assembly LH	72-26
	3. Front seat cushion heater assembly RH	72-26
	4. Front seat back heater assembly LH	72-26
	5. Front seat back heater assembly RH	72-26
	6. Seat heater switch	72-26
	7. Wire harness	–