

DTC	B2795	UNMATCHED KEY CODE
------------	--------------	---------------------------

CIRCUIT DESCRIPTION

This DTC is output when an unregistered key is inserted.

DTC No.	DTC detection condition	Trouble area
B2795	Key with different ID code inserted in ignition switch	Key

INSPECTION PROCEDURE

1	CHECK DTC
----------	------------------

(a) ☐ Clear the DTC. (See page 05-1260)

(b) Check whether the engine starts, after registering of the key that does not start the engine.

OK

NO PROBLEM

NG

REPLACE KEY THAT DOES NOT START ENGINE
