

PROBLEM SYMPTOMS TABLE

| Symptom | Suspected Area | See page |
|--|---|---------------------------|
| Engine does not crank (does not start) | 1. Starter 2. ST relay 3. Park/neutral position switch | 19-14 19-14 40-7 |
| No initial combustion (does not start) | 1. ECM power source circuit 2. Fuel pump control circuit 3. ECM | 05-298 05-303 01-32 |
| No complete combustion (does not start) | 1. Fuel pump control circuit | 05-303 |
| Difficult to start (engine cranks normally) | 1. Starter signal circuit 2. Fuel pump control circuit 3. Compression | 05-234 05-303 14-1 |
| Difficult to start with cold engine | 1. Starter signal circuit 2. Fuel pump control circuit | 05-234 05-303 |
| Difficult to start with hot engine | 1. Starter signal circuit 2. Fuel pump control circuit | 05-234 05-303 |
| High engine idle speed (poor idling) | 1. A/C signal circuit (Compressor circuit) 2. ECM power source circuit | 05-1434 05-298 |
| Low engine idle speed (poor idling) | 1. A/C signal circuit (Compressor circuit) 2. Fuel pump control circuit | 05-1434 05-303 |
| Rough idling (poor idling) | 1. Compression 2. Fuel pump control circuit | 14-1 05-303 |
| Hunting (poor idling) | 1. ECM power source circuit 2. Fuel pump control circuit | 05-298 05-303 |
| Hesitation/Poor acceleration (poor driveability) | 1. Fuel pump control circuit 2. A/T faulty | 05-303 05-1123 |
| Surging (poor driveability) | 1. Fuel pump control circuit | 05-303 |
| Engine stalls soon after starting | 1. Fuel pump control circuit | 05-303 |
| Engine stalls during A/C operation | 1. A/C signal circuit (Compressor circuit) 2. ECM | 05-1434 01-32 |
| Unable to refuel/Difficult to refuel | 1. ORVR system | – |