

Service Hints

R19 Remote Control Mirror SW

- 8—Ground : Approx. 12 volts with ignition SW at ACC or ON position
- 7—Ground : Always continuity
- 8—6 : Continuity with the operation SW at DOWN or RIGHT position
- 6—7 : Continuity with the operation SW at UP or LEFT position

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
M1	43 (LHD)	M2	43 (LHD)	R19	A 43 (LHD)
	53 (RHD)		53 (RHD)		B 53 (RHD)

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2H	28	Floor Wire and Driver Side J/B (Lower Finish Panel)

□ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA1	60 (LHD)	Front Door LH Wire and Floor Wire (Left Kick Panel)
IB1	60 (LHD)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
	72 (RHD)	
IB2	60 (LHD)	
	72 (RHD)	
IL1	62 (LHD)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
	74 (RHD)	
IL2	74 (RHD)	
IN1	74 (RHD)	Front Door RH Wire and Floor Wire (Right Kick Panel)

▽ : Ground Points

Code	See Page	Ground Points Location
BO	64 (LHD)	Under the Driver's Seat
BP	76 (RHD)	

○ : Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I4	62 (LHD)	Instrument Panel Wire	B2	64 (LHD)	Front Door LH Wire
	74 (RHD)		B11	76 (RHD)	Front Door RH Wire