

# Illumination

## Service Hints

### TAIL Relay

5-3 : Closed with the light control SW at TAIL or HEAD position

### C11 Combination SW

14-16 : Closed with the light control SW at TAIL or HEAD position

## ○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A17	40 (LHD)	C11	50 (RHD)	R3	C
	50 (RHD)	G1	41 (LHD)	R8	A
A21	40 (LHD)		51 (RHD)		51 (RHD)
	50 (RHD)	H14	41 (LHD)	R9	D
B5	40 (LHD)		51 (RHD)		51 (RHD)
	50 (RHD)	H15	41 (LHD)	R10	41 (LHD)
B7	40 (LHD)	J2	41 (LHD)		51 (RHD)
	50 (RHD)		51 (RHD)	R11	41 (LHD)
C4	40 (LHD)	J4	41 (LHD)		51 (RHD)
	50 (RHD)		51 (RHD)	S3	41 (LHD)
C5	40 (LHD)	J12	41 (LHD)		51 (RHD)
	50 (RHD)		51 (RHD)	S4	41 (LHD)
C7	40 (LHD)	R2	41 (LHD)		51 (RHD)
	50 (RHD)		51 (RHD)		
C11	40 (LHD)	R3	C		

## ○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B (Engine Compartment Left)

## ○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2E	28	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2M	29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2Q		
2R		
3A	34 (LHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
	35 (RHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace LH)

## ▽ : Ground Points

Code	See Page	Ground Points Location
II	60 (LHD)	Cowl Side Panel LH
IK	60 (LHD)	Instrument Panel Brace LH
IL	60 (LHD)	Instrument Panel Brace RH
	72 (RHD)	
IM	72 (RHD)	Instrument Panel Brace RH
IN	72 (RHD)	Instrument Panel Reinforcement RH

