



OVERHAUL

1. REMOVE CONSOLE BOX CARPET (SEE PAGE 71-16)
2. REMOVE RR CONSOLE BOX (SEE PAGE 71-16)
3. REMOVE FRONT ASH RECEPTACLE ASSY (W/ ASHTRAY) (SEE PAGE 71-16)
4. REMOVE CONSOLE BOX FRONT (SEE PAGE 71-16)
5. REMOVE AIR DUCT REAR NO.1 (SEE PAGE 71-16)
6. REMOVE AIR DUCT REAR NO.2 (SEE PAGE 71-16)
7. REMOVE CONSOLE BOX DUCT NO.1 (SEE PAGE 71-16)



8. DISCONNECT FLOOR SHIFT PARKING LOCK CABLE ASSY

- (a) Disconnect the floor shift parking lock cable from the floor shift assy.




9. DISCONNECT TRANSMISSION CONTROL CABLE ASSY


- (a) Disconnect the floor shift cable transmission control shift from the floor shift assy.

10. REMOVE FLOOR SHIFT ASSY


- (a) Disconnect the shift lock control computer connector.
- (b) Disconnect the transmission control switch connector.




- (c) Remove the 4 bolts and transmission floor shift assy.

**11. REMOVE INDICATOR LAMP WIRE SUB-ASSY**


- (a) Releasing the lock by pressing the slick, disconnect the indicator lamp wire connector from the shift lever plate.
- (b) Disconnect the indicator lamp wire sub-assy from the position indicator housing.




- (c) Remove the indicator lamp cap and indicator lamp bulb from the indicator lamp wire sub-assy.

**12. REMOVE SHIFT LEVER KNOB SUB-ASSY**


- (a) Remove the 2 screws and shift lever knob from the shift lever.




- (b) Using a screwdriver, release the stopper of the connector.
- (c) Using a small screwdriver, disengage the locking lug of the terminals 3 and 7, and pull out the terminals from the rear.

**13. REMOVE POSITION INDICATOR SLIDE COVER**


- (a) Remove the position indicator slide cover from the floor shift assy.

**14. REMOVE TRANSMISSION CONTROL SWITCH**


- (a) Using a screwdriver, remove the transmission control switch from the shift lever knob.

**15. REMOVE SHIFT LEVER KNOB BUTTON**

- (a) Using a screwdriver, release the claw and remove the shift lever knob button.
 (b) Remove the compression spring.

**16. REMOVE POSITION INDICATOR HOUSING UPPER**


- (a) Using a screwdriver, disengage the 4 claws and remove the position indicator housing upper from the floor shift assy.

**17. REMOVE POSITION INDICATOR HOUSING COVER**


- (a) Using a screwdriver, remove the position indicator housing cover from the position indicator housing upper.

18. REMOVE POSITION INDICATOR SLIDE COVER


- (a) Remove the position indicator slide cover from the floor shift assy.
- (b) Remove the position indicator slide cover No.2 from the floor shift assy.

**19. REMOVE SHIFT LOCK RELEASE BUTTON**


- (a) While pressing the 2 claws, remove the shift lock release button and shift lock release spring.

**20. REMOVE POSITION INDICATOR LIGHT GUIDE**


- (a) Disengage the 2 claws and remove the position indicator lamp shade from the position indicator housing lower.



- (b) Remove the position indicator light guide from the position indicator housing lower.


**21. REMOVE POSITION INDICATOR HOUSING LOWER**

- (a) Using a screwdriver, pry up the shift lever nut No.1.
- (b) Using a screwdriver, pry up the floor shift lever lock pin.
- (c) Using a screwdriver release the 2 claws and remove the position indicator housing lower from the floor shift assy.




22. REMOVE TRANSMISSION CONTROL SWITCH

- (a) Using a screwdriver, remove the transmission control switch from the floor shift assy.




- (b) Using a screwdriver, release the stopper of the connector.
 (c) Using a small screwdriver, disengage the locking lug of the terminals 1, 2 and 6 and pull the terminals out from the rear.




23. INSTALL TRANSMISSION CONTROL SWITCH

- (a) Install the 3 terminals into the indicator lamp wire connector.



- (b) Install the transmission control switch to the floor shift assy.




24. INSTALL POSITION INDICATOR HOUSING LOWER

- (a) Install the position indicator housing lower with the shift lever lock pin and a new shift lever nut No.1.


HINT:

Ensure that the claws fit tightly.




25. INSTALL POSITION INDICATOR LIGHT GUIDE

- (a) Install the position indicator light guide to the position indicator housing lower.



- (b) Install the position indicator lamp shade to the position indicator housing lower.



26. INSTALL SHIFT LOCK RELEASE BUTTON


- (a) Apply MP grease to the shift lock release spring and shift lock release button.
- (b) Install the shift lock release button and shift lock release spring to the position indicator housing lower.

HINT:

Ensure that the claws fit tightly.

27. INSTALL POSITION INDICATOR SLIDE COVER

- (a) Install the position indicator slide cover No.2 to the position indicator.
- (b) Install the position indicator slide cover to the floor shift assy.




28. INSTALL POSITION INDICATOR HOUSING COVER

- (a) Install the position indicator housing cover to the position indicator housing upper.

HINT:

Ensure that the claws fit tightly.




29. INSTALL POSITION INDICATOR HOUSING UPPER

- (a) Install the control position indicator housing upper.

HINT:

Ensure that the claws fit tightly.



30. INSTALL SHIFT LEVER KNOB BUTTON

- (a) Apply MP grease to the shift lever knob button and compression spring and install them to the shift lever knob.

HINT:


Ensure that the claws fit tightly.

31. INSTALL TRANSMISSION CONTROL SWITCH

- (a) Install the transmission control switch to the shift lever knob.


HINT:

Ensure that the claws fit tightly.




32. INSTALL POSITION INDICATOR SLIDE COVER

- (a) Install the position indicator slide cover to the floor shift assy.




33. INSTALL SHIFT LEVER KNOB SUB-ASSY

- (a) Install the 2 terminals into the indicator lamp wire connector.




- (b) Install the shift lever knob to the shift lever with 2 screws.




34. INSTALL INDICATOR LAMP WIRE SUB-ASSY

- (a) Install the indicator lamp bulb and indicator lamp cap to the indicator lamp wire.
- (b) Install the indicator lamp wire to the position indicator housing lower.



- (c) Install the indicator lamp wire harness and connector as shown in the illustration.




35. INSTALL FLOOR SHIFT ASSY

- (a) Install the floor shift assy to the vehicle with the 4 bolts.
Torque: 12 N·m (122 kgf·cm, 9 ft·lbf)

HINT:

Tighten them in the order, A, B, C and D.

- (b) Connect the transmission control switch connector.
- (c) Connect the shift lock control computer connector.




36. CONNECT TRANSMISSION CONTROL CABLE ASSY

- (a) Connect the floor shift cable to the floor shift assy.

HINT:

- Install it with the uneven surface facing to up.
- Ensure that the claws fit tightly.



37. CONNECT FLOOR SHIFT PARKING LOCK CABLE ASSY

- (a) Set the accessory tool.

- (1) Shift the shift lever to P position and turn the ignition switch to the LOCK position. (TMC made)
- (2) Shift the shift lever to N position and turn the ignition switch to the ACC. position (TMMK made)
- (3) Set the accessory tool to the shift lock control unit assy as shown in the illustration.


Accessory tool parts No.:

TMC Made: 33693-33010


TMMK Made: 33693-06010

HINT:

Only in the case of reusing the shift lock control unit assy.




- (b) Using a screwdriver, unlock the claw of the lock key of automatic adjustment part.



- (c) Insert the lever pin into the hole in the floor shift parking lock cable.

HINT:

Ensure that the claws fit tightly.



(d) Lock the lock key.

HINT:

- At this time, the shift lever should be in P position and the ignition key should be set to LOCK position. (TMC Made)
- At this time, the shift lever should be in N position and the ignition key should be set to ACC position. (TMMK Made)

(e) Remove the accessory tool.

Accessory tool parts NO.:

TMC Made: 33693-33010

TMMK Made: 33693-06010

38. CHECK KEY INTERLOCK OPERATION (SEE PAGE 40-51)
39. CHECK SHIFT LOCK OPERATION (SEE PAGE 40-51)
40. CHECK SHIFT LOCK RELEASE BUTTON OPERATION (SEE PAGE 40-51)
41. INSTALL CONSOLE BOX DUCT NO.1 (SEE PAGE 71-16)
42. INSTALL AIR DUCT REAR NO.2 (SEE PAGE 71-16)
43. INSTALL AIR DUCT REAR NO.1 (SEE PAGE 71-16)
44. INSTALL CONSOLE BOX FRONT (SEE PAGE 71-16)
45. INSTALL FRONT ASH RECEPTACLE ASSY (W/ ASHTRAY) (SEE PAGE 71-16)
46. INSTALL RR CONSOLE BOX (SEE PAGE 71-16)
47. INSTALL CONSOLE BOX CARPET (SEE PAGE 71-16)