


| | | |
|-----|----------|---------------------------|
| DTC | C1249/58 | STOP LIGHT SWITCH CIRCUIT |
|-----|----------|---------------------------|

CIRCUIT DESCRIPTION

This circuit recognizes brake operation by sending a stop light signal to the skid control ECU.

| DTC No. | DTC Detecting Condition | Trouble Area |
|----------|---|---|
| C1249/58 | Stop light switch circuit is open, and stop lamp switch voltage is in the level between 40 % and 70 % of the battery voltage. | <ul style="list-style-type: none">• Stop light switch• Stop light switch circuit |

WIRING DIAGRAM



INSPECTION PROCEDURE

1 INSPECT STOP LAMP SWITCH ASSY

- (a) Check that the stop lamp comes on when the brake pedal is depressed and goes off when the brake pedal is released.

HINT:


Check the stop lamp bulb as it may have burnt out.

Standard: Stop lamp switch function is normal.

NG Go to step 4

OK

2 INSPECT SKID CONTROL ECU TERMINAL VOLTAGE(STP TERMINAL)



- (a) Disconnect the skid control ECU connector.
(b) Measure the voltage according to the value(s) in the table below.

Standard:


| Tester Connection | Switch Condition | Specified Condition |
|---------------------------|-----------------------|---------------------|
| S1-20 (STP) – Body ground | Brake pedal depressed | 8 to 14 V |
| S1-20 (STP) – Body ground | Brake pedal released | Below 4.0 V |

OK REPLACE BRAKE ACTUATOR ASSY (See page 32-58)


NG

3 CHECK HARNESS AND CONNECTOR(STOP LAMP SWITCH – SKID CONTROL ECU)

Skid Control ECU Connector Front View



Stop Lamp Switch Connector Front View



- Disconnect the stop lamp switch connector and skid control ECU connector.
- Measure the resistance according to the value(s) in the table below.

Standard:

| Tester Connection | Specified Condition |
|---------------------------|---------------------|
| S1-20 (STP) – S14-1 (STP) | Below 1Ω |

NG


REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE
(See page 05-883)

4 INSPECT STOP LAMP SWITCH ASSY

Stop Lamp Switch Assy



- Disconnect the stop lamp switch assy connector.
- Measure the resistance according to the value(s) in the table below.

Standard:


| Switch Condition | Tester Connection | Specified Condition |
|----------------------|-------------------|---------------------|
| Switch pin free | 1 – 2 | Below 1Ω |
| Switch pin pushed in | 1 – 2 | 10 kΩ or higher |

NG

REPLACE STOP LAMP SWITCH ASSY

OK

5 CHECK HARNESS AND CONNECTOR(STOP LAMP CIRCUIT)



- (a) Disconnect the stop lamp switch connector and skid control ECU connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard:

| Tester Connection | Specified Condition |
|---------------------------|---------------------|
| S1-20 (STP) – S14-1 (STP) | Below 1Ω |

OK REPLACE BRAKE ACTUATOR ASSY
(See page 32-58)

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR