


DTC	P1120/19	ACCELERATOR PEDAL POSITION SENSOR CIRCUIT MALFUNCTION
------------	-----------------	--

HINT:

Specification for the Australian vehicles are "Accelerator Position Sensor Circuit Malfunction".

CIRCUIT DESCRIPTION

Accelerator pedal position sensor is mounted on the accelerator pedal bracket and it has 2 sensors to detect the accelerator position and a malfunction of the accelerator position's own. In the accelerator pedal position sensor, the voltage applied to the terminals VPA and VPA2 of the ECM changes between 0 V and 5 V in proportion to the opening angle of the accelerator pedal. The ECM judges the current opening angle of the accelerator pedal from these signals input from terminals VPA and VPA2 and the ECM controls the throttle motor based on these signals. If this DTC is stored, the ECM shuts down the power for the throttle motor, and the throttle valve is fully closed by the return spring.




DTC No.	DTC Detecting Condition	Trouble Area
P1120/19	Condition (a), (b), (c), (d) or (e) continues for 0.5 seconds: (Idle is ON: 10 seconds) (a) $VPA \leq 0.2 \text{ V}$ (b) $VPA2 \leq 0.5 \text{ V}$ (c) $VPA \geq 4.8 \text{ V}$ (d) When $VPA \geq 0.2 \text{ V}$ and $\leq 3.45 \text{ V}$, and $VPA2 \geq 4.8 \text{ V}$ (e) $VPA - VPA2 \leq 0.02 \text{ V}$ (f) Idle is OFF	<ul style="list-style-type: none"> • Open or short in accelerator pedal position sensor circuit • Accelerator pedal position sensor • ECM
	Condition (a) or (b) continues for 2.0 seconds: (a) $VPA \leq 0.2 \text{ V}$ and $VPA2 \leq 0.5 \text{ V}$	

HINT:

After confirming DTC P1120/19, use the hand-held tester to confirm the throttle valve opening percentage.

Accelerator pedal position expressed as voltage				Trouble area
Accelerator pedal released		Accelerator pedal depressed		
ACCEL POS #1	ACCEL POS #2	ACCEL POS #1	ACCEL POS #2	
0V	0V	0V	0V	VCPA,VCP2 circuit open
0V	0.9－2.3V	0V	3.4－5.0V	VPA circuit open or ground short
0.5－1.1V	0V	3.0－4.6V	0V	VPA2 circuit open or ground short
5V	5V	5V	5V	EP1,EP2 circuit open

WIRING DIAGRAM




INSPECTION PROCEDURE

HINT:

Read freeze frame data using hand-held tester, as freeze frame data records the engine conditions when a malfunction is detected. When troubleshooting, it is useful for determining whether the vehicle was running or stopped, the engine was warmed up or not, the air-fuel ratio was lean or rich, etc. at the time of the malfunction.

When using Hand-held Tester:

1 READ VALUE OF HAND-HELD TESTER



- Connect the hand-held tester.
- Turn the ignition switch ON.
- Read the voltage for the accelerator pedal position sensor data.


Standard voltage:

Accelerator pedal	VPA	VPA2
Released	0.5 - 1.1 V	0.9 - 2.3 V
Depressed	3.0 - 4.6 V	3.4 - 5.0 V

OK

CHECK AND REPLACE ECM


NG

2 CHECK ECM(VCPA-EPA,VCP2-EPA2)

- (a) Turn the ignition switch ON.
 (b) Measure the voltage between E6 ECM terminals.

Standard voltage:


Tester (+)	Tester (-)	Voltage
VCPA	EPA	4.5 - 5.5 V
VCP2	EPA2	

NG**CHECK AND REPLACE ECM****OK****3 CHECK ECM(VPA-EPA,VPA2-EPA2)**

- (a) Turn the IG switch ON.
 (b) Measure the voltage between E6 ECM terminals.

Standard voltage:

Accelerator pedal	Voltage	
	VPA - EPA	VPA2 - EPA2
Released	0.5 - 1.1 V	0.9 - 2.3 V
Depressed	3.0 - 4.6 V	3.4 - 5.0 V

OK**CHECK AND REPLACE ECM****NG****4 INSPECT ACCELERATOR PEDAL ASSY(POSITION SENSOR)**

- (a) Disconnect the accelerator pedal position sensor connector.
 (b) Measure the resistance between each terminal.

Standard resistance at 20°C (68°F):


Terminals	Resistance
VCP1 - EP1	1.5 - 6.0 kΩ
VCP2 - EP2	

NG

REPLACE ACCELERATOR PEDAL ASSY

OK

5 CHECK WIRE HARNESS(ECM-ACCELERATOR POSITION SENSOR)





- (a) Disconnect the E6 ECM connector.
- (b) Disconnect the accelerator position sensor connector.
- (c) Check the continuity between the terminal E6 ECM connector and A17 accelerator position sensor connector .

Standard (LHD):
(Check for open)

E6 ECM connector terminal	A17 Accelerator position sensor connector	Continuity
VCP2 (27)	VCP2 (4)	Continuity
VPA2 (23)	VPA2 (2)	Continuity
EPA2 (29)	EP2 (1)	Continuity
VCPA (26)	VCP1 (6)	Continuity
VPA (22)	VPA (5)	Continuity
EPA (28)	EP1 (3)	Continuity

(Check for short)

A17 Accelerator position sensor connector	E8 ECM connector	Continuity
VCP2 (4)	E1 (1)	No continuity
VPA2 (2)		No continuity
EP2 (1)		No continuity
VCP1 (6)		No continuity
VPA (5)		No continuity
EP1 (3)		No continuity



Standard (RHD):
(Check for open)

E6 ECM connector terminal	A17 Accelerator position sensor connector	Continuity
VCP2 (27)	VCP2 (6)	Continuity
VPA2 (23)	VPA2 (2)	Continuity
EPA2 (29)	EP2 (3)	Continuity
VCPA (26)	VCP1 (4)	Continuity
VPA (22)	VPA (5)	Continuity
EPA (28)	EP1 (1)	Continuity

(Check for short)

A17 Accelerator position sensor connector	E8 ECM connector	Continuity
VCP2 (6)	E1 (1)	No continuity
VPA2 (2)		No continuity
EP2 (3)		No continuity
VCP1 (4)		No continuity
VPA (5)		No continuity
EP1 (1)		No continuity

NG**REPAIR OR REPLACE WIRE HARNESS****OK****CHECK AND REPLACE ECM****When not using Hand-held Tester:**

Perform the step 2 to 5.