

DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed during the DTC check, check the circuit listed for that code in the table below. (Proceed to the page given for that circuit.)

HINT:

The DTC detection method (See page [05-2148](#)).

DTC No. (See page)	Detection Item	Trouble Area
42 (05-2096)	Wireless door lock receiver circuit malfunction	Body ECU does not receive a corresponding RDA signal within 1 sec. after a PRG signal is output from the body ECU in the diagnosis mode.