

PROBLEM SYMPTOMS TABLE

Proceed to the reference page shown in the matrix chart below for each malfunction symptom and make a troubleshooting for each circuit.

HINT:

Troubleshooting of the theft deterrent system is based on the premise that the door lock control system is operating normally. Accordingly, before troubleshooting the theft deterrent system, first make certain that the door lock control system is operating normally.

Problem Symptom	Suspected Area	See Page
Theft deterrent system cannot be set	1. Indicator light circuit 2. ECU power source circuit 3. Key unlock warning switch circuit 4. Back door key lock and unlock switch circuit 5. Engine hood courtesy switch circuit 6. Door lock control system	05-2146 05-2141 – – – 05-2072
Indicator light does not blink when system is set	1. Indicator light circuit	05-2146
When the system is set (The system does not operate when the engine hood is opened)	1. Engine hood courtesy switch circuit	–
When the system is set (It is not canceled when the ignition key is turned to ACC or ON position)	1. Ignition switch circuit	–
When the system is set (It is still operating when the luggage door is opened with the key)	1. Luggage door key lock and unlock switch circuit	–
While the system is in warning operation (Horn does not sound)	1. Horn circuit	05-2143
Even when the system is not set (Horn sounds)	1. Horn circuit	05-2143