

# CRUISE CONTROL SYSTEM

## HOW TO PROCEED WITH TROUBLESHOOTING

0563T-01



1 VEHICLE BROUGHT TO WORKSHOP

2 CUSTOMER PROBLEM ANALYSIS (See page 05-1289)

3 CHECK AND CLEAR DTC (See page 05-1290)

DTC DOES NOT OUTPUT (PROCEED TO "BODY MULTIPLEX COMMUNICATION SYSTEM")

DTC OUTPUTS (GO TO STEP 4)

4 PROBLEM SYMPTOM CONFIRMATION

SYMPTOM DOES NOT OCCUR (GO TO STEP 5)

SYMPTOM OCCURS (GO TO STEP 6)

5 SYMPTOM SIMULATION (See page 01-21)

6 DTC CHECK (See page 05-1290)

MALFUNCTION CODE (GO TO STEP 7)

NORMAL CODE (GO TO STEP 8)

7 DTC CHART (See page 05-1295)

GO TO STEP 9

8 PROBLEM SYMPTOMS TABLE (See page 05-1298)

9 CIRCUIT INSPECTION (See page 05-1299 - 05-1315)

<b>10</b>	<b>IDENTIFICATION OF PROBLEM</b>
-----------	----------------------------------



<b>11</b>	<b>REPAIR OR REPLACE</b>
-----------	--------------------------



<b>12</b>	<b>CONFIRMATION TEST</b>
-----------	--------------------------



<b>END</b>
------------