


## REVERSE SIGNAL CIRCUIT

### CIRCUIT DESCRIPTION


The radio and navigation assy receives the reverse signal from the park/neutral position switch and information about the GPS antenna, and then adjusts the vehicle position.

### WIRING DIAGRAM



## INSPECTION PROCEDURE

### 1 INSPECT RADIO RECEIVER ASSY



- Disconnect the radio receiver assy connector R12.
- Measure the resistance according to the value(s) in the table below.

#### Standard:


Tester connection	Condition	Specified condition
REV – Body ground	Ignition switch to ON. Shift lever is moved to R position.	10 to 14 V
REV – Body ground	Ignition switch to ON. Shift lever is moved to except R position.	Below 1 V

OK

REPLACE RADIO RECEIVER ASSY

NG

### 2 CHECK HARNESS AND CONNECTOR(RADIO AND NAVIGATION ASSY – PARK/NEUTRAL POSITION SWITCH ASSY)




- Disconnect the connector from the radio and navigation assy R12 and park/neutral position switch assy A4.
- Measure the resistance according to the value(s) in the table below.

#### Standard:

Tester connection	Condition	Specified condition
REV – A4-1	Always	Below 1 $\Omega$
REV – Body ground	Always	10 k $\Omega$ or higher

#### Connector Front View (Park/neutral Position Switch):



NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

REPLACE RADIO AND NAVIGATION ASSY (SEE PAGE 67-5)