

Service Hints

R2 (A), R5 (D) Radio and Player

(A) 3, (D) 18–Ground : Approx. 12 volts with ignition SW at ACC or ON position

(A) 4, (D) 8–Ground : Always approx. 12 volts

(A) 7, (D) 10–Ground : Always continuity

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A35	42 (LHD)	J6	B	41 (LHD)	43 (LHD)
	52 (RHD)			51 (RHD)	53 (RHD)
F10	42 (LHD)	R2	A	41 (LHD)	43 (LHD)
	52 (RHD)			51 (RHD)	53 (RHD)
F11	42 (LHD)	R3	B	41 (LHD)	41 (LHD)
	52 (RHD)			51 (RHD)	51 (RHD)
J3	41 (LHD)	R4	C	41 (LHD)	41 (LHD)
	51 (RHD)			51 (RHD)	51 (RHD)
J5	41 (LHD)	R5	D	41 (LHD)	
	51 (RHD)			51 (RHD)	

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2A	28	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)

□ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IB2	60 (LHD)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
	72 (RHD)	
IC1	72 (RHD)	Instrument Panel Wire and Floor Wire (Right Kick Panel)
IL2	62 (LHD)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
	74 (RHD)	
IM1	62 (LHD)	Instrument Panel Wire and Floor No.2 Wire (Right Kick Panel)
IM2	74 (RHD)	Instrument Panel Wire and Floor No.2 Wire (Left Kick Panel)

▽ : Ground Points

Code	See Page	Ground Points Location
IL	60 (LHD)	Instrument Panel Brace RH
	72 (RHD)	