

## PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See page
Engine does not crank (does not start)	1. Starter 2. ST relay 3. Park/neutral position switch	19-14 19-14 40-7
No initial combustion (does not start)	1. ECM power source circuit 2. Fuel pump control circuit 3. ECM	05-298 05-303 01-32
No complete combustion (does not start)	1. Fuel pump control circuit	05-303
Difficult to start (engine cranks normally)	1. Starter signal circuit 2. Fuel pump control circuit 3. Compression	05-234 05-303 14-1
Difficult to start with cold engine	1. Starter signal circuit 2. Fuel pump control circuit	05-234 05-303
Difficult to start with hot engine	1. Starter signal circuit 2. Fuel pump control circuit	05-234 05-303
High engine idle speed (poor idling)	1. A/C signal circuit (Compressor circuit) 2. ECM power source circuit	05-1434 05-298
Low engine idle speed (poor idling)	1. A/C signal circuit (Compressor circuit) 2. Fuel pump control circuit	05-1434 05-303
Rough idling (poor idling)	1. Compression 2. Fuel pump control circuit	14-1 05-303
Hunting (poor idling)	1. ECM power source circuit 2. Fuel pump control circuit	05-298 05-303
Hesitation/Poor acceleration (poor driveability)	1. Fuel pump control circuit 2. A/T faulty	05-303 05-1134
Surging (poor driveability)	1. Fuel pump control circuit	05-303
Engine stalls soon after starting	1. Fuel pump control circuit	05-303
Engine stalls during A/C operation	1. A/C signal circuit (Compressor circuit) 2. ECM	05-1434 01-32
Unable to refuel/Difficult to refuel	1. ORVR system	–