

## G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number	
A 1	A/C Ambient Temp. Sensor	90980-11070	B 8	Buckle SW LH (LHD)	90980-11950	
A 2	A/C Condenser Fan Motor	90980-10928		Buckle SW LH (RHD w/ Power Seat)	90980-10795	
A 3	A/C Lock Sensor	90980-11016		Buckle SW LH (RHD w/o Power Seat)		
	A/C Magnetic Clutch			Occupant Detection Sensor (RHD w/ Power Seat)		
A 4	A/T Indicator Light SW	90980-12362		Occupant Detection Sensor (RHD w/o Power Seat)		
	Back-Up Light SW	B 9	Buckle SW RH (LHD w/ Power Seat)	90980-10795		
	Neutral Start SW		Buckle SW RH (LHD w/o Power Seat)			
A 5	ABS & BA & TRC & VSC Actuator		90980-12020	Buckle SW RH (RHD)	90980-11950	
A 6	ABS Actuator		90980-12116	Occupant Detection Sensor (LHD w/ Power Seat)	90980-10795	
A 7	ABS Speed Sensor Front LH		90980-11002			Occupant Detection Sensor (LHD w/o Power Seat)
A 8	ABS Speed Sensor Front RH	B10	Buckle SW LH	90980-10942		
A 9	Air Flow Meter		90980-11317		Seat Position Airbag Sensor	
A10	Air Fuel Ratio Sensor (Bank 1 Sensor 1)	90980-11178	B11		Buckle SW RH	
A11	Air Fuel Ratio Sensor (Bank 1 Sensor 1)				Seat Position Airbag Sensor	
A12	Air Fuel Ratio Sensor (Bank 2 Sensor 1)	90980-11856	C 1	Camshaft Position Sensor	90980-10947	
A13	Airbag Sensor Front LH		C 2	Counter Gear Speed Sensor	90980-11156	
A14	Airbag Sensor Front RH	90980-09213	C 3	Crankshaft Position Sensor	90980-10947	
A15	Alternator		C 4	Cigarette Lighter	90980-11606	
A16	Alternator	90980-11964		Cigarette Lighter Illumination		
A17	A/C Control Assembly	90980-12169	C 5	Clock	90980-12200	
A18	A/C Room Temp. Sensor	90980-11918	C 7	Combination Meter	90980-12170	
A19	A/C Solar Sensor		C 8	Combination Meter	90980-12200	
A20	A/C Thermistor	90980-12211	C 9	Combination SW	90980-11594	
A21	A/T Shift Lever Illumination		C10	Combination SW	90980-12183	
	O/D Main SW	90980-11144	C11	Combination SW (LHD)	90980-11672	
A22	Accelerator Position Sensor			Combination SW (RHD)	90980-11671	
A23	Air Inlet Control Servo Motor	90980-11909	C12	Cruise Control Clutch SW	90980-10906	
A24	Air Mix Control Servo Motor		C15	Curtain Shield Airbag Squib LH	90980-12219	
A25	Air Vent Mode Control Servo Motor		C16	Curtain Shield Airbag Squib RH		
A26	Airbag Sensor Assembly	90980-12392	D 1	Diode (A/C No.1)	90980-11071	
A27	Airbag Sensor Assembly	90980-12391	D 2	Diode (A/C No.2)	90980-10962	
A28	Airbag Sensor Assembly	90980-12390	D 3	DLC3	90980-11665	
A29	Airbag Squib (Front Passenger Airbag Assembly)	90980-12160	D 5	Door Control Receiver	90980-11909	
	Airbag Squib (Steering Wheel Pad)		D 6	Door Courtesy SW Front LH	90980-10871	
A31	Airbag Squib (Steering Wheel Pad)	90980-11107	D 7	Door Courtesy SW Front RH		
A32	Automatic Light Control Sensor		D 8	Door Courtesy SW Rear LH		
A33	ABS Speed Sensor Rear LH	90980-11060	D 9	Door Courtesy SW Rear RH		
A34	ABS Speed Sensor Rear RH		D10	Door Key Lock and Unlock SW Front LH	90980-12226	
A35	Auto Antenna Control Relay	90980-10797		Door Lock Motor Front LH		
B 1	Back-Up Light SW	90980-11250		Door Unlock Detection SW Front LH		
B 2	Brake Fluid Level Warning SW	90980-11207	D11	Door Key Lock and Unlock SW Front RH		
B 3	Blower Motor	90980-10385		Door Lock Motor Front RH		
B 4	Blower Motor Controller	90980-11676		Door Unlock Detection SW Front RH		
B 5	Body ECU	90980-11915				
B 6	Body ECU	90980-11913				
B 7	Body ECU	90980-10803				

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number	Code	Part Name	Part Number
D12	Door Lock Control SW Front LH	90980-12122	H 6	Headlight LH (Low)	90980-11149
	Power Window Master SW		H 7	Headlight RH (High)	90980-11095
D13	Door Lock Control SW Front RH		H 8	Headlight RH (Low)	90980-11149
	Power Window Master SW		H 9	Heated Oxygen Sensor (Bank 1 Sensor 2)	90980-11930
D14	Door Lock Motor Rear LH	90980-12226	H10	Heated Oxygen Sensor (Bank 1 Sensor 2)	90980-10869
	Door Unlock Detection SW Rear LH		H11	Heated Oxygen Sensor (Bank 2 Sensor 2)	90980-11028
D15	Door Lock Motor Rear RH		H12	Horn (High)	90980-10619
	Door Unlock Detection SW Rear RH		H13	Horn (Low)	
E 1	ECT Solenoid	90980-11658	H14	Headlight Beam Level Control SW	90980-10996
E 2	EFI Water Temp. Sensor (1MZ-FE)	90980-10737	H15	Headlight Cleaner SW	90980-10964
	EFI Water Temp. Sensor (2AZ-FE, 1AZ-FE)	90980-10735	H16	High Mounted Stop Light (w/ Rear Spoiler)	90980-11060
E 3	EGR Gas Temp. Sensor	90980-10899		High Mounted Stop Light (w/o Rear Spoiler)	90980-11148
E 4	EGR Valve Position Sensor	90980-11143	I 1	Ignition Coil and Igniter No.1	90980-11885
E 5	Engine Oil Level Sensor (1MZ-FE)	90980-11235	I 2	Ignition Coil and Igniter No.2	
	Engine Oil Level Sensor (2AZ-FE, 1AZ-FE)	90980-10532	I 3	Ignition Coil and Igniter No.3	
E 6	Engine and ECT ECU (A/T)	90980-12525	I 4	Ignition Coil and Igniter No.4	
	Engine ECU (M/T)		I 5	Ignition Coil and Igniter No.5	
E 7	Engine and ECT ECU (A/T)	90980-12146	I 6	Ignition Coil and Igniter No.6	
	Engine ECU (M/T)		I 7	Injector No.1 (1MZ-FE)	90980-11153
E 8	Engine and ECT ECU (A/T)	90980-12143		Injector No.1 (2AZ-FE, 1AZ-FE)	90980-11875
	Engine ECU (M/T)	I 8	Injector No.2 (1MZ-FE)	90980-11153	
E 9	Engine and ECT ECU (A/T)		90980-12145		Injector No.2 (2AZ-FE, 1AZ-FE)
	Engine ECU (M/T)	I 9	Injector No.3 (1MZ-FE)	90980-11153	
E10	Engine and ECT ECU (A/T)		90980-12144		Injector No.3 (2AZ-FE, 1AZ-FE)
	Engine ECU (M/T)	I10	Injector No.4 (1MZ-FE)	90980-11153	
F 1	Front Clearance Light LH		90980-10887		Injector No.4 (2AZ-FE, 1AZ-FE)
F 2	Front Clearance Light RH	I11	Injector No.5	90980-11153	
F 3	Front Fog Light LH	90980-11096	I12		Injector No.6
F 4	Front Fog Light RH		I14	Ignition Key Cylinder Light	90980-12092
F 5	Front Side Turn Signal Light LH	90980-11162		Transponder Key Amplifier	
F 6	Front Side Turn Signal Light RH	I15	Ignition SW	90980-11615	
F 7	Front Turn Signal Light LH	90980-11019	I16	Inner Mirror	90980-11794
F 8	Front Turn Signal Light RH		I17	Interior Light	90980-10908
F 9	Front Wiper Motor	90980-11599	J 1	Junction Connector (LHD 1MZ-FE, RHD)	90980-11542
F10	Front Door Speaker LH (LHD)	82824-12260		Junction Connector (LHD 2AZ-FE, 1AZ-FE)	90980-12346
	Front Door Speaker LH (RHD)	90980-10935	J 2	Junction Connector	90980-11542
F11	Front Door Speaker RH (LHD)	82824-12260	J 4	Junction Connector	90980-10976
	Front Door Speaker RH (RHD)	90980-10935	J 5	Junction Connector	90980-11661
F12	Fuel Pump	90980-11077	J 6	Junction Connector	
	Fuel Sender		J 7	Junction Connector	
G 1	Glove Box Light and SW	90980-11098	J 8	Junction Connector	
H 1	Headlight Beam Level Control Actuator LH	90980-11016	J11	Junction Connector	90980-10976
H 2	Headlight Beam Level Control Actuator RH		J12	Junction Connector	90980-11915
H 3	Headlight Cleaner Motor	90980-11410	J13	Junction Connector	
H 4	Headlight Cleaner Relay	90980-10939			
H 5	Headlight LH (High)	90980-11095			

## G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
J14	Junction Connector	90980-12374	P18	Power Seat Motor (Driver's Seat Front Vertical Control)	90980-10825
J15	Junction Connector		P19	Power Seat Motor (Driver's Seat Lifter Control)	
J16	Junction Connector		P20	Power Seat Motor (Driver's Seat Reclining Control)	
J17	Junction Connector		P21	Power Seat Motor (Driver's Seat Slide Control)	
K 1	Knock Sensor (Bank 1)	90980-11166	P22	Power Seat Motor (Front Passenger's Seat Front Vertical Control)	
K 2	Knock Sensor (Bank 1)		P23	Power Seat Motor (Front Passenger's Seat Lifter Control)	
K 3	Knock Sensor (Bank 2)		P24	Power Seat Motor (Front Passenger's Seat Reclining Control)	
K 4	Kick Down SW	90980-11156	P25	Power Seat Motor (Front Passenger's Seat Slide Control)	
L 1	License Plate Light LH	90980-11148	P26	Power Seat Control SW (Driver's Seat Lumbar Support Control)	90980-10789
L 2	License Plate Light RH		P27	Power Seat Motor (Driver's Seat Lumbar Support Control)	90980-10825
L 3	Light Failure Sensor	90980-10803	R 1	Radiator Fan Motor	90980-10928
L 4	Luggage Compartment Door Opener Motor	90980-10825	R 2	Radio and Player	90980-10997
	Luggage Compartment Light SW		R 3	Radio and Player	90980-10996
L 5	Luggage Compartment Light	90980-11148	R 4	Radio and Player	90980-10803
M 1	Mirror Heater LH	90980-12059	R 5	Radio and Player	90980-10819
	Remote Control Mirror LH		R 6	Radio and Player with Display	90980-11923
M 2	Mirror Heater RH		R 7	Radio and Player with Display	90980-11909
	Remote Control Mirror RH		R 8	Radio and Player with Display	90980-10997
M 3	Moon Roof Control ECU and Motor	90980-10997	R 9	Radio and Player with Display	90980-10996
M 4	Moon Roof Control SW	90980-10789	R10	Rear Fog Light SW	90980-12113
	Personal Light		R11	Rheostat	90980-11950
N 1	Noise Filter (Ignition)	90980-10843	R12	Rain Sensor	82824-50130
N 2	Navigation ECU	90980-11973	R13	Rear Combination Light LH	90980-11587
N 3	Navigation ECU	90980-11923	R14	Rear Combination Light RH	
N 4	Noise Filter	90980-10860	R15	Rear Speaker LH	90980-11299
O 1	Oil Pressure Sensor	90980-11363	R16	Rear Speaker RH	
P 1	Power Steering Oil Pressure SW	90980-11428	R17	Rear Window Defogger (LHD)	90980-10913
P 2	Pressure SW	90980-10943		Rear Window Defogger (RHD)	90980-10914
P 3	Parking Brake SW	90980-10871	R18	Rear Window Defogger (LHD)	90980-10914
P 4	Power Outlet (Front)	90980-10760		Rear Window Defogger (RHD)	90980-10913
P 5	Power Outlet (Rear)	90980-10860	R19	Remote Control Mirror SW	90980-11657
P 6	Power Window Control SW Front LH	90980-10789	R20	Radio and Player with Display	90980-10803
P 7	Power Window Control SW Front RH	82824-12230	R21	Radio and Player with Display	90980-10819
P 8	Power Window Control SW Rear LH	90980-10789	R22	Radio and Player with Display	90980-12259
P 9	Power Window Control SW Rear RH	82824-12230	R24	Radio and Player	
P10	Power Window Motor Front LH (LHD)	82824-12270	R25	Radio and Player	90980-11533
	Power Window Motor Front LH (RHD)	90980-10797	S 1	Starter	90980-11400
P11	Power Window Motor Front RH (LHD)	82824-12270	S 2	Starter	90980-09463
	Power Window Motor Front RH (RHD)	90980-10797	S 3	Seat Heater SW LH	90980-10964
P12	Power Window Motor Rear LH	90980-10797			
P13	Power Window Motor Rear RH				
P14	Pretensioner LH	90980-12253			
P15	Pretensioner RH				
P16	Power Seat Control SW (Driver's Seat)	90980-10997			
P17	Power Seat Control SW (Front Passenger's Seat)				

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number	Code	Part Name	Part Number
S 4	Seat Heater SW RH	90980-10933	T 6	Tweeter LH	90980-11013
S 5	Shift Lock Control ECU	90980-11909	T 7	Tweeter RH	
S 6	Skid Control ECU	90980-11638	T 8	Throttle Control Motor	90980-11858
S 7	Skid Control ECU	90980-11637		Throttle Position Sensor	
S 8	Skid Control ECU	90980-11476	U 1	Unlock Warning SW	90980-10860
S 9	Skid Control ECU	90980-11421	V 1	VSV (ACIS)	90980-11149
S10	Skid Control ECU	90980-11392	V 2	VSV (AICV)	90980-11156
S11	Skid Control ECU	90980-11391	V 3	VSV (EGR)	90980-11149
S12	Skid Control ECU	90980-11390	V 4	VSV (EVAP)	90980-11156
S13	Steering Sensor	90980-12162	V 5	VVT Solenoid	90980-11162
S14	Stop Light SW	90980-11118	V 6	VSC Warning Buzzer	90980-10906
S15	Side Airbag Sensor Front LH	90980-12241	V 7	Vanity Light LH	90980-10621
S16	Side Airbag Sensor Front RH		V 8	Vanity Light RH	
S17	Seat Heater LH	90980-10906	W 1	Washer Motor	90980-10981
S18	Seat Heater RH		W 2	Water Temp. SW No.1	90980-11235
S19	Side Airbag Squib LH	90980-11864	W 3	Water Temp. SW No.2	90980-11243
S20	Side Airbag Squib RH		W 4	Wiper Relay	90980-12166
S21	Side Airbag Sensor Rear LH	90980-12241	Y 1	Yaw Rate Sensor	90980-12080
S22	Side Airbag Sensor Rear RH		Z 1	Option Connector (Engine Hood Courtesy SW)	90980-11051
T 1	Throttle Control Motor	90980-11156	Z 2	Option Connector (TVSS ECU) (LHD)	90980-10795
T 2	Throttle Position Sensor	90980-10711		Option Connector (TVSS ECU) (RHD)	90980-11915
T 3	Turbine Speed Sensor	90980-11156	Z 3	Option Connector (TVSS Siren)	90980-10988
T 4	TRC OFF SW	90980-11013			
T 5	Turn Signal Flasher Relay	90980-10799			