

CD CANNOT BE EJECTED

INSPECTION PROCEDURE

1 PRESS "EJECT" AND CHECK OPERATION

(a) Press "EJECT" and check the operation.

- (1) Press the CD EJECT switch of the radio receiver assembly for 2 seconds or more to see if the CD is ejected.

OK: CD is ejected.

NG

REPLACE RADIO RECEIVER ASSY (SEE PAGE 67-4)

OK

2 REPLACE CD WITH ANOTHER AND RECHECK

(a) Replace the CD with another and recheck.

- (1) Replace the CD with another normal one to see if the same trouble occurs again.

OK: Malfunction disappears.

NG

REPLACE RADIO RECEIVER ASSY (SEE PAGE 67-4)

OK

CD IS FAULTY