

## PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See page
Power seat does not operate	1. Front power seat switch 2. PWR SEAT fuse 3. Wire harness	<a href="#">72-3</a> – –
Power seat does not slide	1. Front power seat switch 2. Front slide power seat motor assy (Slide) 3. Wire harness	<a href="#">72-3</a> <a href="#">72-3</a> –
Front vertical of the power seat does not operate (Driver's seat only)	1. Front power seat switch 2. Front up, down power seat motor assy (Front vertical) 3. Wire harness	<a href="#">72-3</a> <a href="#">72-3</a> –
Rear lifter of the power seat does not slide operate (Driver's seat only)	1. Front power seat switch 2. Power seat motor assy (Rear vertical) 3. Wire harness	<a href="#">72-3</a> <a href="#">72-3</a> –
Power seat does not reclining	1. Front power seat switch 2. Power seat motor assy (Reclining) 3. Wire harness	<a href="#">72-3</a> <a href="#">72-3</a> –