

System Outline

The current always flows from the STOP fuse into TERMINAL 2 of the stop light SW. If the brake pedal is depressed, the stop lights light up.

Stop Light Disconnection Warning

If any stop light wiring is faulty when the brake pedal is depressed with the ignition SW set at ON, the light failure sensor detects a voltage difference and is activated to turn on the rear lights warning light in the combination meter to warn the driver. The warning light is remained lit until the ignition SW is turned to the OFF position.

Service Hints

S14 Stop Light SW

1-2 : Closed with the brake pedal depressed

L3 Light Failure Sensor

7-Ground : Approx. 12 volts with the stop light SW on

8-Ground : Approx. 12 volts with the ignition SW at ON position

11-Ground : Always continuity

○ : Parts Location

Code		See Page	Code	See Page	Code	See Page
C7	A	50 (RHD)	L3	53 (RHD)	R14	53 (RHD)
C8	B	50 (RHD)	N4	53 (RHD)	S14	51 (RHD)
H16		52 (RHD)	R13	53 (RHD)		

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1C	25	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
2G	28	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2K	28	Floor Wire and Driver Side J/B (Lower Finish Panel)
2M	29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2O		
3A	35 (RHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace LH)

□ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	72 (RHD)	Instrument Panel Wire and Floor Wire (Right Kick Panel)
IC3	72 (RHD)	Instrument Panel Wire and Floor MWire (Right Kick Panel)

▽ : Ground Points

Code	See Page	Ground Points Location
BR	76 (RHD)	Front Side of Rear Quarter Wheel House RH
BS	76 (RHD)	Lower Back Panel Center

○ : Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
B4	76 (RHD)	Floor Wire	B9	76 (RHD)	Floor Wire
B7			B17		