

## Service Hints

### I16 Inner Mirror

2—Ground : Approx. 12 volts with ignition SW at ON or ST position

1—Ground : Always continuity

### ○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
I16	42 (LHD)	J7	A	41 (LHD)	
	52 (RHD)	J13	B	51 (RHD)	

### ○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2B	28	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)

### □ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IE1	60 (LHD)	Instrument Panel Wire and Roof Wire (Inside of Front Left Pillar)
	72 (RHD)	Instrument Panel Wire and Roof Wire (Inside of Front Right Pillar)

### ▽ : Ground Points

Code	See Page	Ground Points Location
IJ	72 (RHD)	Instrument Panel Reinforcement LH
IM	60 (LHD)	Instrument Panel Reinforcement RH