

# Clock

## Service Hints

### C5 Clock

- 20–Ground : Approx. 12 volts with ignition SW at ON or ST position  
 22–Ground : Approx. 12 volts with ignition SW at ACC or ON position  
 24–Ground : Always approx. 12 volts  
 1–Ground : Always continuity

## ○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A1	36 (LHD 1MZ–FE)	C5	50 (RHD)	F12	42 (LHD)
	38 (*1)		40 (LHD)		52 (RHD)
	46 (RHD 1MZ–FE)	C7	50 (RHD)	I7	37 (LHD 1MZ–FE)
	48 (*2)		40 (LHD)		39 (*1)
A17	40 (LHD)	C8	50 (RHD)		47 (RHD 1MZ–FE)
	50 (RHD)		40 (LHD)		49 (*2)
C5	40 (LHD)	C10			
			50 (RHD)		

\* 1 : LHD 2AZ–FE, 1AZ–FE      \* 2 : RHD 2AZ–FE, 1AZ–FE

## ○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1L	25	Engine Wire and Engine Room J/B (Engine Compartment Left)
2K	28	Floor Wire and Driver Side J/B (Lower Finish Panel)
2L	29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2M		
2O		
2R		
3A	34 (LHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
	35 (RHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace LH)
3B	34 (LHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
	35 (RHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace LH)

## □ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC2	72 (RHD)	Instrument Panel Wire and Floor Wire (Right Kick Panel)
IF3	60 (LHD)	Engine Room Main Wire and Instrument Panel Wire (Right Side of Steering Column Tube)
	72 (RHD)	Engine Room Main Wire and Instrument Panel Wire (Left Side of Steering Column Tube)
II1	62 (LHD)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Reinforcement RH)
	74 (RHD)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)
IK1	62 (LHD)	Engine Wire and Instrument Panel Wire (Behind the Glove Box)
	74 (RHD)	
IM2	74 (RHD)	Instrument Panel Wire and Floor No.2 Wire (Left Kick Panel)

## ▽ : Ground Points

Code	See Page	Ground Points Location
II	60 (LHD)	Cowl Side Panel LH
IJ	60 (LHD)	Instrument Panel Brace LH
IK	72 (RHD)	
IN	72 (RHD)	Instrument Panel Reinforcement RH

## ○ : Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E3	56 (LHD 1MZ–FE)	Engine Wire	E5	58 (*1)	Engine Wire
	68 (RHD 1MZ–FE)			70 (*2)	

\* 1 : LHD 2AZ–FE, 1AZ–FE      \* 2 : RHD 2AZ–FE, 1AZ–FE

