


POWER SOURCE CIRCUIT (AUTO ANTENNA CONTROL RELAY)

CIRCUIT DESCRIPTION


This circuit provides the power to the auto antenna control relay.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 INSPECT AUTO ANTENNA CONTROL RELAY (B, ACC, IG, E)



- (a) Disconnect the auto antenna control relay connector A35.
- (b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
E - Body ground	Always	Below 1 Ω

- (c) Measure the voltage according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
B - E	Always	10 to 4 V
IG - E	Ignition SW ON	10 to 4 V
ACC - E	Ignition SW ACC	10 to 4 V

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE
(SEE PAGE 05-46)