


## Ts Terminal Circuit

### CIRCUIT DESCRIPTION

In the sensor check mode, a malfunction of the speed sensor that cannot be judged when the vehicle is stopped is judged while driving.


Transition to the sensor check mode can be performed by connecting terminals Ts and CG of the DLC3 and turning the ignition switch from OFF to ON.

### WIRING DIAGRAM



### INSPECTION PROCEDURE

#### 1 INSPECT DLC3



- Turn the ignition switch ON.
- Measure voltage between terminals Ts and CG of DLC3.  
**OK: 10 - 14 V**

**OK** → **Go to step 3**

**NG**

#### 2 CHECK HARNESS AND CONNECTOR (DLC3 - SKID CONTROL ECU ASSY AND DLC3 - BODY GROUND) (See page 01-31)


**NG** → **REPAIR OR REPLACE HARNESS OR CONNECTOR**

**OK**

#### CHECK AND REPLACE SKID CONTROL ECU ASSY

**3 CHECK ABS WARNING LIGHT**

SST 09843-18040



- (a) Using SST, connect the terminals Ts and CG of the DLC3.
- (b) Check the ABS and VSC warning right.

**OK: Warning light blinking****OK****END****NG****CHECK AND REPLACE SKID CONTROL ECU ASSY**