

LIST OF DISABLE A MONITOR

HINT:

This table indicates ECM monitoring status for the items in the upper columns if the DTCs in each line on the left are being set.

As for the "X" mark, when the DTC on the left is stored, detection of the DTC in the upper column is not performed.

Monitor detected malfunction				Monitor disablement (X – disabled)																	
	Fault code	Fault code	Component/ system	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0030,50	P0135,P0155	P0036,56	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121
				P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100-P0103	P0101	P0105-P0108	P0106	P0110-P0113	P0115-P0118	P0116	P0120-P0223,P2135
				VVT VSV 1, 2	VVT System 1 – Advance	VVT System 1 – Retard	VVT System – Misalignment	VVT System 2 – Advance	VVT System 2 – Retard	O2 Sensor Heater–Sensor1	A/F Sensor Heater–Sensor1	O2 Sensor Heater–Sensor2	O2 Sensor Heater–Sensor3	MAF sensor	MAF sensor	MAP sensor	MAP sensor	IAT sensor	ECT sensor	ECT sensor	TP sensor
	P0010,P0020	P0010,P0020	VVT VSV 1, 2																		
	P0011	P0011	VVT System 1 – Advance																		
	P0012	P0012	VVT System 1 – Retard																		
	P0016,P0018	P0016,P0018	VVT System – Misalignment																		
	P0021	P0021	VVT System 2 – Advance																		
	P0022	P0022	VVT System 2 – Retard																		
	P0030,50	P0031,32,51,52	O2 Sensor Heater–Sensor1																		
	P0135,P0155	P0031,32,51,52	A/F Sensor Heater–Sensor1																		
	P0036,56	P0037,38,57,58	O2 Sensor Heater–Sensor2																		
	P0043,44,63,64	P0043,44,63,64	O2 Sensor Heater–Sensor3																		
	P0100,P0101	P0100-P0103	MAF sensor																		
	P0105,P0106	P0105-P0108	MAP sensor																		
	P0110	P0110-P0113	IAT sensor																		
	P0115,P0116	P0115-P0118	ECT sensor																		
	P0120,P0121	P0120-P0223,P2135	TP sensor																		
	P0125	P0125	Insufficient ECT for Closed Loop																		
	P0128	P0128	Thermostat																		
	P0130-P0153	P0130-P0153	O2 Sensor–Sensor1																		
	P0134,P0154	P0134,P0154	O2 Sensor, A/F sensor (No Activity)–Sensor1																		
	P0136,P0156	P0136,P0156	O2 Sensor–Sensor2																		
	P0142,P0162	P0142,P0162	O2 Sensor–Sensor3																		
	P0171,P0172	P0171,P0172	Fuel system																		
	P0300-P0308	P0300-P0308	Misfire																		
	P0325,P0330	P0325-P0333	Knock sensor																		
	P0335	P0335	CKP sensor																		
	P0340,P0341	P0340,P0341	CMP sensor																		
	P0340-P0346	P0340-P0346	VVT sensor 1, 2																		
	P0351-P0358	P0351-P0358	Ignitor																		
	P0385	P0385	CKP sensor 2																		
	P0401	P0401	EGR system (closed)																		
	P0402	P0402	EGR system (open)																		
	P0405,P0409	P0405-P0409	Lift sensor																		
	P0420,P0430	P0420,P0430	Catalyst																		
	P0442-P0456	P0442-P0456	EVAP system																		
	P0450,P0451	P0450-P0453	EVAP press sensor																		

Monitor detected malfunction	Fault code			Monitor disablement (X – disabled)																			
	Fault code			Monitor disablement (X – disabled)																			
	Fault code			Monitor disablement (X – disabled)																			
	Component/ system			Monitor disablement (X – disabled)																			
P0500	P0500	VSS	VVT VSV 1, 2	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0030,50	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
P0511	P0511	IAC valve	VVT System 1 – Advance	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P0510	P0510	Idle switch	VVT System 1 – Retard	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P0560	P0560	System Voltage	VVT System – Misalignment	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P0617	P0617	Starter signal	VVT System 2 – Advance	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P0705	P0705	Shift lever position switch	VVT System 2 – Retard	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P0710	P0710-P0713	Trans fluid temp sensor	O2 Sensor Heater-Sensor1	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P0720-P0793	P0720-P0793	Output speed sensor	A/F Sensor Heater-Sensor1	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P0715-P0717	P0715-P0717	Input speed sensor	O2 Sensor Heater-Sensor2	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P0724	P0724	Stop lamp switch	O2 Sensor Heater-Sensor3	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P0741-P0796	P0741-P0796	Trans solenoid (function)	MAF sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P0748-P0798	P0748-P0798	Trans solenoid (range)	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P0850	P0850	PNP switch	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P1010,P1020	P1010,P1020	VVTL	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P1011,12(,21,22)	P1011,12(,21,22)	VVTL system1(,2)	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P1126	P1126	Electronic magnet clutch	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P1129	P1129	Electronic throttle system	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P1430	P1430	HC absorber ACT press sensor	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P2004,6	P2004,6	Intake Manifold Runner Control	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P2009,10	P2009,10	Intake Manifold Runner Control Circuit	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P2014,16,17	P2014,16,17	Intake Manifold Runner Position Sensor	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P2102,P2103	P2102,P2103	Throttle motor	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P2120-P2138	P2120-P2138	Accel position sensor	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P2196,P2198	P2196,P2198	A/F sensor (rationality)	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P2226	P2226	BARO sensor	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P2237,2240	P2237,2240	A/F sensor (open)	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P2423,24	P2423,24	HC Absorption Catalyst	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P2430,2,3	P2430,2,3	A/R Pressure Sensor (Low/High)	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P2431	P2431	A/R Pressure Sensor (Rationality)	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P2440	P2440	A/R control valve stuck open	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P2441	P2441	A/R control valve stuck close	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P2444	P2444	AIP stuck On	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P2445	P2445	AIP stuck Off	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P2714-P2759	P2714-P2759	Trans solenoid (SLU-SLD)	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153
P2A00,P2A03	P2A00,P2A03	A/F sensor (slow response)	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128	P0130,P0153

Monitor detected malfunction	Fault code		Monitor disablement (X – disabled)	
	Fault code		Monitor disablement (X – disabled)	
	Component/ system		Monitor disablement (X – disabled)	
P0010,P0020	P0010,P0020	VVT VSV 1, 2		X
P0011	P0011	VVT System 1 – Advance		
P0012	P0012	VVT System 1 – Retard		
P0016,P0018	P0016,P0018	VVT System – Misalignment		
P0021	P0021	VVT System 2 – Advance		
P0022	P0022	VVT System 2 – Retard		
P0030,50	P0031,32,51,52	O2 Sensor Heater–Sensor1		X
P0135,P0155	P0031,32,51,52	A/F Sensor Heater–Sensor1		
P0036,56	P0037,38,57,58	O2 Sensor Heater–Sensor2		
P0043,44,63,64	P0043,44,63,64	O2 Sensor Heater–Sensor3		
P0100,P0101	P0100-P0103	MAF sensor		X
P0105,P0106	P0105-P0108	MAP sensor		X
P0110	P0110-P0113	IAT sensor		X
P0115,P0116	P0115-P0118	ECT sensor		X
P0120,P0121	P0120-P0223,P2135	TP sensor		X
P0125	P0125	Insufficient ECT for Closed Loop		X
P0128	P0128	Thermostat		
P0130-P0153	P0130-P0153	O2 Sensor–Sensor1		X
P0134,P0154	P0134,P0154	O2 Sensor, A/F sensor (No Activity)–Sensor1		X
P0136,P0156	P0136,P0156	O2 Sensor–Sensor2		
P0142,P0162	P0142,P0162	O2 Sensor–Sensor3		
P0171,P0172	P0171,P0172	Fuel system		X
P0300-P0308	P0300-P0308	Misfire		X
P0325,P0330	P0325-P0333	Knock sensor		X
P0335	P0335	CKP sensor		X
P0340,P0341	P0340,P0341	CMP sensor		X
P0340-P0346	P0340-P0346	VVT sensor 1, 2		
P0351-P0358	P0351-P0358	Ignitor		X
P0385	P0385	CKP sensor 2		X
P0401	P0401	EGR system (closed)		X
P0402	P0402	EGR system (open)		X
P0405,P0409	P0405-P0409	Lift sensor		
P0420,P0430	P0420,P0430	Catalyst		
P0442-P0456	P0442-P0456	EVAP system		X
P0450,P0451	P0450-P0453	EVAP press sensor		
		Knock sensor	P0325-P0333	P0325,P0330
		CKP sensor	P0335	P0335
		CMP sensor	P0340,P0341	P0340,P0341
		VVT sensor 1, 2	P0340-P0346	P0340-P0346
		Ignitor	P0351-P0358	P0351-P0358
		CKP sensor 2	P0385	P0385
		EGR system (closed)	P0401	P0401
		EGR system (open)	P0402	P0402
		EGR Lift sensor	P0405,P0406	P0405
		EGR Lift sensor	P0409	P0409
		Catalyst	P0420,P0430	P0420,P0430
		EVAP system	P0440-P0446	P0440-P0446
		EVAP press sensor	P0450-P0453	P0450,P0451
		VSS (ECT2 sensor)	P0500	P0500
		VSS (ECT1 sensor, non-ECT)	P0500	P0500
		VSS (M/T)	P0500	P0500
		IAC valve	P0511	P0511
		Idle switch	P0510	P0510
		System Voltage	P0560	P0560
		Starter signal	P0617	P0617
		Shift lever position switch	P0705	P0705
		Trans fluid temp sensor	P0710-P0713	P0710
		Output speed sensor	P0720-P0793	P0720-P0793
		Input speed sensor	P0715-P0717	P0715-P0717
		Stop lamp switch	P0724	P0724
		Trans solenoid (function)*1	P0741-P0796	P0741-P0796

			Monitor disablement (X – disabled)															
Monitor detected malfunction	Fault code	Fault code	Component/ system	P0325,P0330	P0335	P0340,P0341	P0340-P0346	P0351-P0358	P0385	P0401	P0402	P0405	P0409	P0420,P0430	P0440-P0446	P0450,P0451	P0500	P0500
				P0325-P0333	P0335	P0340,P0341	P0340-P0346	P0351-P0358	P0385	P0401	P0402	P0405,P0406	P0409	P0420,P0430	P0440-P0446	P0450-P0453	P0500	P0500
				Knock sensor	CKP sensor	CMP sensor	VVT sensor 1, 2	Igniter	CKP sensor 2	EGR system (closed)	EGR system (open)	EGR Lift sensor	EGR Lift sensor	Catalyst	EVAP system	EVAP press sensor	VSS (ECT2 sensor)	VSS (ECT1 sensor, non-ECT)
	P0500	P0500	VSS						X	X				X	X			
	P0511	P0511	IAC valve														X	
	P0510	P0510	Idle switch							X				X	X		X	
	P0560	P0560	System Voltage															
	P0617	P0617	Starter signal															
	P0705	P0705	Shift lever position switch															
	P0710	P0710-P0713	Trans fluid temp sensor															
	P0720-P0793	P0720-P0793	Output speed sensor															
	P0715-P0717	P0715-P0717	Input speed sensor															
	P0724	P0724	Stop lamp switch															
	P0741-P0796	P0741-P0796	Trans solenoid (function)															
	P0748-P0798	P0748-P0798	Trans solenoid (range)															
	P0850	P0850	PNP switch														X	
	P1010,P1020	P1010,P1020	VVTL															
	P1011,12(,21,22)	P1011,12(,21,22)	VVTL system1(,2)						X	X				X	X		X	
	P1126	P1126	Electronic magnet clutch															
	P1129	P1129	Electronic throttle system															
	P1430	P1430	HC absorber ACT press sensor											X	X			
	P2004,6	P2004,6	Intake Manifold Runner Control															
	P2009,10	P2009,10	Intake Manifold Runner Control Circuit															
	P2014,16,17	P2014,16,17	Intake Manifold Runner Position Sensor															
	P2102,P2103	P2102,P2103	Throttle motor															
	P2120-P2138	P2120-P2138	Accel position sensor															
	P2196,P2198	P2196,P2198	A/F sensor (rationality)						X	X			X				X	
	P2226	P2226	BARO sensor															
	P2237,2240	P2237,2240	A/F sensor (open)						X	X			X				X	
	P2423,24	P2423,24	HC Absorption Catalyst															
	P2430,2,3	P2430,2,3	A/R Pressure Sensor (Low/High)															
	P2431	P2431	A/R Pressure Sensor (Rationality)															
	P2440	P2440	A/R control valve stuck open						X	X			X					
	P2441	P2441	A/R control valve stuck close						X	X			X					
	P2444	P2444	AIP stuck On						X	X			X					
	P2445	P2445	AIP stuck Off						X	X			X					
	P2714-P2759	P2714-P2759	Trans solenoid (SLU-SLD)															
	P2A00,P2A03	P2A00,P2A03	A/F sensor (slow response)						X	X			X				X	

Monitor detected malfunction				Monitor disablement (X – disabled)																										
	Fault code	Fault code	Component/ system																											
P0010,P0020	P0010,P0020	VVT VSV 1, 2																												
P0011	P0011	VVT System 1 – Advance																												
P0012	P0012	VVT System 1 – Retard																												
P0016,P0018	P0016,P0018	VVT System – Misalignment																												
P0021	P0021	VVT System 2 – Advance																												
P0022	P0022	VVT System 2 – Retard																												
P0030,50	P0031,32,51,52	O2 Sensor Heater–Sensor1																												
P0135,P0155	P0031,32,51,52	A/F Sensor Heater–Sensor1																												
P0036,56	P0037,38,57,58	O2 Sensor Heater–Sensor2																												
P0043,44,63,64	P0043,44,63,64	O2 Sensor Heater–Sensor3																												
P0100,P0101	P0100-P0103	MAF sensor																												
P0105,P0106	P0105-P0108	MAP sensor																												
P0110	P0110-P0113	IAT sensor																												
P0115,P0116	P0115-P0118	ECT sensor																												
P0120,P0121	P0120-P0223,P2135	TP sensor																												
P0125	P0125	Insufficient ECT for Closed Loop																												
P0128	P0128	Thermostat																												
P0130-P0153	P0130-P0153	O2 Sensor–Sensor1																												
P0134,P0154	P0134,P0154	O2 Sensor, A/F sensor (No Activity)–Sensor1																												
P0136,P0156	P0136,P0156	O2 Sensor–Sensor2																												
P0142,P0162	P0142,P0162	O2 Sensor–Sensor3																												
P0171,P0172	P0171,P0172	Fuel system																												
P0300-P0308	P0300-P0308	Misfire																												
P0325,P0330	P0325-P0333	Knock sensor																												
P0335	P0335	CKP sensor																												
P0340,P0341	P0340,P0341	CMP sensor																												
P0340-P0346	P0340-P0346	VVT sensor 1, 2																												
P0351-P0358	P0351-P0358	Igniter																												
P0385	P0385	CKP sensor 2																												
P0401	P0401	EGR system (closed)																												
P0402	P0402	EGR system (open)																												
P0405,P0409	P0405-P0409	Lift sensor																												
P0420,P0430	P0420,P0430	Catalyst																												
P0442-P0456	P0442-P0456	EVAP system																												
P0450,P0451	P0450-P0453	EVAP press sensor																												

				Monitor disablement (X – disabled)																									
Monitor detected malfunction	Fault code	Fault code	Component/ system	P0741-P0796	P0748-P0798	P0850	P1010,P1020	P1011,12(,21,22)	P1126	P1129	P1430	P2004,6	P2009,P2010	P2014,16,17	P2102,P2103	P2120-P2138	P2196,P2198	P2226	P2237,P2240	P2423,24	P2430,2,3	P2431	P2440	P2441	P2444	P2445	P2714-P2759	P2A00,P2A03	
				Trans solenoid (function) *2	Trans solenoid (range)	PNP switch	VVTL	VVTL system1(,2)	Electronic magnet clutch	Electronic throttle system	HC absorber ACT press sensor	Intake Manifold Runner Control	Intake Manifold Runner Control Circuit	Intake Manifold Runner Position Sensor	Throttle motor	Accel position sensor	A/F Sensor (Rationality) -Sensor1	BARO sensor	A/F Sensor (Open) -Sensor1	HC Absorption Catalyst	A/R Pressure Sensor (Low/High)	A/R Pressure Sensor (Rationality)	A/R control valve stuck open	A/R control valve stuck close	AIP stuck On	AIP stuck Off	Trans solenoid (SLU-SLD)	A/F sensor (Slow response) -Sensor1	
	P0500	P0500	VSS	X													X			X	X		X	X					
	P0511	P0511	IAC valve														X		X										
	P0510	P0510	Idle switch														X		X	X									
	P0560	P0560	System Voltage																										
	P0617	P0617	Starter signal																										
	P0705	P0705	Shift lever position switch																										
	P0710	P0710-P0713	Trans fluid temp sensor																										
	P0720-P0793	P0720-P0793	Output speed sensor																										
	P0715-P0717	P0715-P0717	Input speed sensor																										
	P0724	P0724	Stop lamp switch																										
	P0741-P0796	P0741-P0796	Trans solenoid (function)																										
	P0748-P0798	P0748-P0798	Trans solenoid (range)	X																									
	P0850	P0850	PNP switch																										
	P1010,P1020	P1010,P1020	VVTL																										
	P1011,12(,21,22)	P1011,12(,21,22)	VVTL system1(,2)																				X	X	X	X		X	
	P1126	P1126	Electronic magnet clutch																				X	X	X	X			
	P1129	P1129	Electronic throttle system																										
	P1430	P1430	HC absorber ACT press sensor																										
	P2004,6	P2004,6	Intake Manifold Runner Control																										
	P2009,10	P2009,10	Intake Manifold Runner Control Circuit																										
	P2014,16,17	P2014,16,17	Intake Manifold Runner Position Sensor																										
	P2102,P2103	P2102,P2103	Throttle motor																										
	P2120-P2138	P2120-P2138	Accel position sensor																										
	P2196,P2198	P2196,P2198	A/F sensor (rationality)																				X	X	X	X		X	
	P2226	P2226	BARO sensor																				X	X	X	X		X	
	P2237,2240	P2237,2240	A/F sensor (open)																				X	X	X	X		X	
	P2423,24	P2423,24	HC Absorption Catalyst																										
	P2430,2,3	P2430,2,3	A/R Pressure Sensor (Low/High)																				X	X	X	X			
	P2431	P2431	A/R Pressure Sensor (Rationality)																					X	X	X	X		
	P2440	P2440	A/R control valve stuck open																									X	
	P2441	P2441	A/R control valve stuck close																									X	
	P2444	P2444	AIP stuck On																									X	
	P2445	P2445	AIP stuck Off																									X	
	P2714-P2759	P2714-P2759	Trans solenoid (SLU-SLD)																										
	P2A00,P2A03	P2A00,P2A03	A/F sensor (slow response)																										