

# WIPER AND WASHER SYSTEM

6604P-01

## PRECAUTION

### 1. PRECAUTION OF WASHER NOZZLE ADJUSTMENT

- (a) Do not clean or adjust the washer nozzle with a safety pin etc. because;
  - (1) the washer nozzle tip is made of resin and could be damaged.
  - (2) adjustment is not necessary because the washer nozzle is spray type.
- (b) In case the washer nozzle is clogged with wax etc., remove the objects and clean the nozzle hole with a soft resin brush etc.