

ENGINE IMMOBILIZER SYSTEM

HOW TO PROCEED WITH TROUBLESHOOTING

055VD-02

Troubleshoot in accordance with the procedure on the following pages.

1 VEHICLE BROUGHT IN

2 CUSTOMER PROBLEM ANALYSIS CHECK AND PROBLEM SYMPTOM CONFIRMATION (See page 05-1259)

3 CRANK ENGINE FOR MORE THAN 10 SECONDS

4 CHECK DIAGNOSTICS TROUBLE CODE OF ECM (See page 05-1260)

- (a) When any of codes B2795, B2796, B2797 and B2798 is output, proceed to "A".
- (b) When a code except B2795, B2796, B2797 and B2798 is output or no code is output, proceed to "B".

B REFER TO EFI SYSTEM

(1AZ-FE engine: See page 05-17)

(2AZ-FE engine: See page 05-145)

(1MZ-FE engine: See page 05-301)

A

5 CHECK DIAGNOSTICS TROUBLE CODE (See page 05-1262)

- (a) Check a DTC and note it if a code is output.
- (b) Delete the DTC.
- (c) Check if the DTC will be output once again, when the problem symptom is simulated based on the noted code.
 - (1) Without an output of the code, proceed to "A".
 - (2) With an output of the code, proceed to "B".

B NORMAL

A

6 ACCORDING TO PROBLEM SYMPTOM, PERFORM TROUBLESHOOTING

- (a) Pre-check (See page 05-1260)
 - (1) Inspection with hand-held tester (ECU data list)
- (b) Terminals of ECU (See page 05-1264)

7	ADJUSTMENT, REPAIR OR REPLACE
----------	--------------------------------------



END
