

DTC	B1185/57	SHORT IN P SQUIB (2ND STEP) CIRCUIT
------------	-----------------	--


CIRCUIT DESCRIPTION

The P squib (2nd step) circuit consists of the airbag sensor assy center and instr pnl pass l/door airbag assy. It causes the SRS to deploy when the SRS deployment conditions are satisfied.

DTC B1185/57 is recorded when a short is detected in the P squib (2nd step) circuit.


DTC No.	DTC Detecting Condition	Trouble Area
B1185/57	<ul style="list-style-type: none"> • Short circuit in P squib (2nd step) wire harness • P squib (2nd step) malfunction • Airbag sensor assy center malfunction 	<ul style="list-style-type: none"> • Instr pnl pass l/door airbag assy (P squib, 2nd step) • Airbag sensor assy center • Instrument panel wire

WIRING DIAGRAM



INSPECTION PROCEDURE

1 CHECK P-SQUIB CIRCUIT (AIRBAG SENSOR ASSY CENTER - INSTR PNL PASS L/DOOR AIRBAG ASSY)




- Disconnect the negative (-) terminal cable from the battery, and wait at least for 90 seconds.
- Disconnect the connectors between the airbag sensor assy center and the instr pnl pass l/door airbag assy.
- Release the airbag activation prevention mechanism of the connector (on the airbag sensor assy center side) between the airbag sensor assy center and the instr pnl pass l/door airbag assy (See page 05-758).
- For the orange connector (on the instr pnl pass l/door airbag assy side) between the airbag sensor assy center and the instr pnl pass l/door airbag assy, measure the resistance between P2+ and P2-.

OK:**Resistance: 1 MΩ or Higher****NG**
REPAIR OR REPLACE WIRE HARNESS (AIRBAG SENSOR ASSY CENTER - INSTR PNL PASS L/DOOR AIRBAG ASSY)
OK

2 CHECK AIR BAG SENSOR ASSY CENTER

SST 09843-18040



- Connect the connector to the airbag sensor assy center.
- Connect the negative (-) terminal cable to the battery, and wait at least for 2 seconds.
- Turn the ignition switch to ON, and wait at least for 20 seconds.
- Clear the DTC stored in memory (See page 05-758).
- Turn the ignition switch to LOCK, and wait at least for 20 seconds.
- Turn the ignition switch to ON, and wait at least for 20 seconds.
- Check the DTC (See page 05-758).


OK:**DTC B1185/57 is not output.****HINT:**

Codes other than code B1185/57 may be output at this time, but they are not relevant to this check.

NG
REPLACE AIR BAG SENSOR ASSY CENTER
OK

3 CHECK P SQUIB

SST 09843-18040



- Turn the ignition switch to LOCK.
- Disconnect the negative (-) terminal cable from the battery, and wait at least for 90 seconds.
- Connect the Instr Pnl Pass L/door air bag Assy connectors.
- Connect the negative (-) terminal cable to the battery, and wait at least for 2 seconds.
- Turn the ignition switch to ON, and wait at least for 20 seconds.
- Clear the DTC stored in memory (See page 05-758).
- Turn the ignition switch to LOCK, and wait at least for 20 seconds.
- Turn the ignition switch to ON, and wait at least for 20 seconds.
- Check the DTC (See page 05-758).

OK:**DTC B1185/57 is not output.****HINT:**

Codes other than code B1185/57 may be output at this time, but they are not relevant to this check.

NG**REPLACE INSTR PNL PASS L/DOOR AIR BAG ASSY****OK****USE SIMULATION METHOD TO CHECK**