


## INSPECTION



### 1. INTAKE AIR CONTROL VALVE ASSY

- (a) With 26.7 kPa (200 mm Hg, 7.9 in. Hg) of vacuum applied to the actuator, check that the actuator rod moves.
- (b) One minute after applying the vacuum, check that the actuator rod does not return.
- (c) If the operation is not as specified, replace the intake air control valve assembly.

#### NOTICE:



**Do not adjust the adjust screw.**

### 2. INTAKE AIR CONTROL VALVE ASSY NO.3

- (a) Inspect actuator operation
  - (1) With 26.7 kPa (200 mm Hg, 7.9 in. Hg) of vacuum applied to the actuator, check that the actuator rod moves.
  - (2) One minute after applying the vacuum, check that the actuator rod does not return.
  - (3) If the operation is not as specified, replace the intake air control valve No.3.
- (b) Inspect VSV operation
  - (1) Using an ohmmeter, check that there is continuity between each terminals.


**Resistance: 37 – 44  $\Omega$  at 20°C (68°F)**

- (2) Check that air flows from port E to the filter.
- (3) Apply battery voltage across the terminals.
- (4) Check that air flows from port E to port F.



### 3. AIR CLEANER CAP SUB-ASSY

- (a) Cover port C with finger, and check that air flows from port B to port A.
- (b) Cover port C with finger, and check that air does not flow from port A to port B.
- (c) Cover port A and C with fingers, and apply 60 kPa (450 mm Hg, 18 in. Hg) of vacuum to port B, and check that there is no change of vacuum after one minute.



#### 4. VACUUM SWITCHING VALVE ASSY NO.1

- (a) Using an ohmmeter, check that there is continuity between each terminals.

**Resistance: 33 – 39  $\Omega$  at 20°C (68°F)**

- (b) Check that air flows from port B to the filter.  
(c) Apply battery voltage across the terminals.  
(d) Check that air flows from port B to port A.