

F RELAY LOCATIONS

① : Engine Room R/B

Engine Compartment Left (See Page 20)

* 1:1MZ-FE
* 2:2AZ-FE, 1AZ-FE

