

PLAYBACK SPEED/SCRATCH

By default playback speed are sent by step sequencer B.
\$75: normal speed
\$25: reverse normal speed

- Source selection to trigger **Pitch values suite**

→ Apply to free play /step off

 Apply to sampled audio/step on

- Choose a pitch values for each step

Rampe values received ; Glide

B: send Step seq B values to playback speed

B: send Step seq B step off= silence

Receive ADJR from step_seq B

