



# **Hardware setup appears to hang (SG5600)**

## **StorageGRID**

NetApp  
March 03, 2022

This PDF was generated from <https://docs.netapp.com/us-en/storagegrid-116/sg5600/he-error-error-synchronizing-with-santricity-os-software.html> on March 03, 2022. Always check docs.netapp.com for the latest.

# Table of Contents

Hardware setup appears to hang (SG5600) .....	1
HE error: Error synchronizing with SANtricity OS Software .....	1

# Hardware setup appears to hang (SG5600)

The StorageGRID Appliance Installer might not be available if hardware faults or cabling errors prevent the E5600SG controller from completing its boot-up processing.

### Steps

1. Check the Needs Attention LED on either controller and look for a flashing error code.

During power up, the Service Action Allowed and Service Action Required LEDs are turned on while the hardware is initializing. The upper decimal point of the lower digit, called the *diagnostic LED*, also illuminates. The seven-segment display runs through a sequence of codes that are common for both controllers. This is normal and is not an indication of an error. When the hardware boots successfully, the Service Action LEDs are turned off, and the displays are driven by the firmware.

2. Review the codes on the seven-segment display for the E5600SG controller.



The installation and provisioning take time. Some installation phases do not report updates to the StorageGRID Appliance Installer for several minutes.

If an error occurs, the seven-segment display flashes a sequence, such as HE.

3. To understand what these codes mean, see the following resources:

Controller	Reference
E5600SG controller	<ul style="list-style-type: none"><li>• “HE error: Error synchronizing with SANtricity OS Software”</li><li>• “E5600SG controller seven-segment display codes”</li></ul>
E2700 controller	<p>E-Series documentation</p> <p><b>Note:</b> The codes described for the E-Series E5600 controller do not apply to the E5600SG controller in the appliance.</p>

4. If this does not resolve the issue, contact technical support.

### Related information

[E5600SG controller seven-segment display codes](#)

[HE error: Error synchronizing with SANtricity OS Software](#)

[E2700 Controller-Drive Tray and Related Drive Trays Installation Guide](#)

[NetApp Documentation: E2700 Series](#)

## HE error: Error synchronizing with SANtricity OS Software

The seven-segment display on the compute controller shows an HE error code if the

## StorageGRID Appliance Installer cannot synchronize with SANtricity OS Software.

### About this task

If an HE error code is displayed, perform this corrective action.

### Steps

1. Check the integrity of the two SAS interconnect cables, and confirm they are securely connected.
2. As required, replace one or both of the cables, and try again.
3. If this does not resolve the issue, contact technical support.

## Copyright Information

Copyright © 2022 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

## Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.